

零件手册

Parts Manual

2000C


帶切刀褲耳机

Earphones with cutting knife pants

目 錄

1. 機殼部件 / FRAME ASSEMBLY	1
2. 罩殼部件 / FRAME ASSEMBLY	3
3. 挑綫機構(1702) / THREAD TENSION MECHANISM (1702)	5
4. 軸套部件 / BUSHING	7
5. 針杆部分 / NEEDLE BAR MECHANISM	9
6. 下軸部件 / CRANKSHAFT MECHANISM	11
7. 送布機構 / FEED MECHANISM	13
8. 彎針部件 / LOOPER MECHANISM	15
9. 壓腳部件 / PRESSER FOOT MECHANISM	17
10. 潤滑部件 / LUBRICATION MECHANISM	19
11. 后拖輪部件(P, PMD) / REAR PULLER MECHANISM (P, PMD)	21
12. 后拖輪連接部件 / REAR PULLER MECHANISM	23
13. 前拖輪部件 / METERING DEVICE MECHANISM	25
14. BK專用部件(1) / MODEL BK EXCLUSIVE PARTS (1)	27
15. BK專用部件(2) / MODEL BK EXCLUSIVE PARTS (2)	29
16. EHD專用部件 / MODEL EHD EXCLUSIVE PARTS	31
17. 挑綫機構(1701EHD) / THREAD TENSION MECHANISM (1701EHD)	33
18. 1701EHD專用部件 / MODEL 1701EHD EXCLUSIVE PARTS	35
19. 挑綫機構(1702EHD) / THREAD TENSION MECHANISM (1702EHD)	37
20. 1702EHD專用部件 / MODEL 1702EHD EXCLUSIVE PARTS	39
21. 綫架與臺板部件 / THREAD STAND AND TABLE	41
22. 附件 / ACCESSORIES	43
23. 針位部件 / GAUGE PARTS	45
24. 針位部件 / GAUGE PARTS	47
25. 針位部件 / GAUGE PARTS	49
26. 針位部件一覽表 / GAUGE PARTS TABLE	51


1. 機殼部件 / FRAME ASSEMBLY




REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q' TY
01-01	02-119	波形墊圈	WASHER	1
01-02	21-273	機針防護罩	EYE GUARD	1
01-03	21-275	機針防護罩安裝板	BRACKET	1
01-04	21-276	機針防護罩支架	BRACKET	1
01-05	21-934	針杆防護罩	COVER	1
01-06	21-935	挑綫杆防護罩	COVER	1
01-07	21-972	皮帶罩	PULLEY COVER	1
01-08	23-157	面板墊	GASKET	1
01-09	23-206	蓋板墊	GASKET	1
01-10	23-263	油封	GASKET C	1
01-11	23-285	O型圈	O RING	1
01-12	23-427	面板油封	PLUG	1
01-13	24-052	銘牌	BRAND NAME PLATE	3
01-14	27-017	上蓋板	TOP COVER	1
01-15	27-018	面板	HEAD COVER	1
01-16	39-108	油封壓板	COVER	1
01-17	39-137	油管導板	PIPE SUPPORT	1
01-18	39-234	油窗	OIL POT	1
01-19	75-224	墊圈	WASHER	2
01-20	75-455	墊圈	WASHER	2
01-21	87-010	螺釘	SCREW	3
01-22	87-092	內六角螺釘	BOLT	2
01-23	87-099	螺釘	SCREW	2
01-24	87-123	內六角螺釘	BOLT	1
01-25	87-129	內六角上蓋螺釘	BOLT	9
01-26	87-177	內六角螺釘	BOLT	5
01-27	87-264	螺釘	SCREW	1
01-28	21-712	挑綫杆防護罩	SAFETY PLATE	1
01-29	21-800	墊塊		1
01-30	87-299	內六角螺釘	BOLT	2

2. 罩殼部件 / FRAME ASSEMBLY

P, PMD TYPE







B TYPE




REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q'TY
02-01	14-030	針板座	NEEDLE PLATE SUPPORT BRACKET	1
02-02	14-064	針板座	NEEDLE SUPPORT BRACKET	1
02-03	21-137	前窗板	FRONT COVER	1
02-04	21-227	差板	SLIDE COVER	1
02-05	21-336	后罩殼	COVER B	1
02-06	21-395	上罩殼	UPPER COVER	1
02-07	21-781	上罩殼	UPPER COVER	1
02-08	21-782	前罩殼	FRONT BASE COVER	1
02-09	21-783	護板	COVER	1
02-10	21-784	前鉛固定板	FRONT COVER PLATE	1
02-11	21-785	前鉛板	FRONT COVER	1
02-12	21-897	上蓋板	COVER	1
02-13	23-137	前窗板墊	GASKET	1
02-14	23-229	上蓋板墊	GASKET	1
02-15	23-296	油封	PLUG	1
02-16	23-504	油封	PLUG	1
02-17	23-512	防震墊	CUSHION RUBBER	1
02-18	24-053	機器編號牌	TYPE PLATE	1
02-19	25-226	固定支架	HINGE	1
02-20	25-503	螺釘	SCREW	1
02-21	25-517	螺釘	SCREW	1
02-22	26-712	壓板	WASHER	2
02-23	31-438	油網	FILTER	1
02-24	75-455	墊片	WASHER	3
02-25	75-528	波形墊圈	WASHER	1
02-26	79-801	前罩殼壓簧	SPRING	1
02-27	79-802	壓簧	SPRING	1
02-28	79-922	彈簧墊圈	SPRING	2
02-29	84-117	螺釘	SCREW	2
02-30	84-163	螺釘	SCREW	2
02-31	84-361	螺釘	SCREW	2
02-32	84-574	螺釘	SCREW	2
02-33	84-706	螺釘	SCREW	1
02-34	84-761	螺釘	SCREW	2~3
02-35	84-762	螺釘	SCREW	4
02-36	84-763	螺釘	SCREW	2
02-37	84-862	螺釘	SCREW	2~3
02-38	85-181	螺釘	SCREW	4
02-39	86-266	螺母	NUT	1
02-40	87-096	螺釘	SCREW	3
02-41	87-113	內六角螺釘	BOLT	5
02-42	87-123	內六角螺釘	BOLT	2
02-43	87-261	螺釘	SCREW	5
02-44	87-266	螺釘	SCREW	1
02-45	87-285	內六角螺釘	BOLT	2
02-46	87-286	螺釘	SCREW	1
02-47	87-292	調節螺釘	SCREW	1
02-48	93-701	銷子	PIN	2

3. 挑綫機構(1702) / THREAD TENSION MECHANISM (1702)




REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q' TY
03-01	23-324	氈墊圈	FELT	3
03-02	41-101	夾綫螺母	THREAD TENSION NUT	3
03-03	41-105	夾綫螺母止動板	SPRING POST	3
03-04	41-107	夾綫外殼	SPRING CUP	3
03-05	41-110	夾綫板	TENSION DISC	6
03-06	41-113	松綫頂板	TENSION POST SUPPORT	1
03-07	41-120	過綫板	THREAD EYELET	3
03-08	41-121	夾綫器安裝板	TENSION POST HOLDER	1
03-09	41-132	擋圈	COLLAR	1
03-10	41-312	壓綫支架	BRACKET	1
03-11	41-510	夾綫螺釘	SCREW STUD	3
03-12	41-701	夾綫彈簧(強)	SPRING (HEAVY)	2
03-13	41-702	夾綫彈簧(弱)	SPRING (LIGHT)	1
03-14	41-721	彈簧	SPRING	1
03-15	43-335	卡簧	LOOPER THREAD RETAINER WIRE	1
03-16	43-344	導綫器	THREAD GUIDE	1
03-17	43-346	支架	BRACKET	1
03-18	43-519	下過綫板	THREAD EYELET	3
03-19	45-101	上過綫板	THREAD EYELET	1
03-20	45-121	挑綫杆	THREAD EYELET	1
03-21	45-131	針杆挑綫杆	THREAD EYELET	1
03-22	45-142	壓綫板	THREAD EYELET	1
03-23	45-429	針杆擋綫板	THREAD TAKE-UP PLATE	1
03-24	45-441	機針上過綫板	THREAD EYELET	1
03-25	45-442	機針下過綫板	THREAD EYELET	1
03-26	47-131	下過綫(左)	THREAD EYELET	1
03-27	47-132	下過綫(右)	THREAD EYELET	1
03-28	71-191	銷子	PIN	2
03-29	75-455	墊圈	WASHER	2
03-30	75-456	墊圈	WASHER	1
03-31	75-468	墊圈	WASHER	1
03-32	84-161	螺釘	SCREW	3
03-33	74-171	螺釘	SCREW	1
03-34	84-361	螺釘	SCREW	3
03-35	84-374	螺釘	SCREW	1
03-36	84-764	螺釘	SCREW	1
03-37	86-411	螺母	NUT	2
03-38	87-097	螺釘	SCREW	1
03-39	87-177	內六角螺釘	BOLT	2
03-40	87-293	螺釘	SCREW	4
03-41	87-272	螺釘	SCREW	1
03-42	40-3810	彎針過綫組件	LOOPER THREAD EYELET ASS'Y	1

4. 軸套部件 / BUSHING




REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q'TY
04-01	71-255	銷子	PIN	2
04-02	71-256	銷子	PIN	2
04-03	75-436	墊圈	WASHER	4
04-04	81-109	后拖輪中套	BUSHING	1
04-05	81-133	后拖輪堅套	BUSHING	1
04-06	81-153	壓杆套	BUSHING	1
04-07	81-181	針杆上套	BUSHING	1
04-08	81-183	針杆下套	BUSHING	1
04-09	81-184	針杆下套	BUSHING	1
04-10	81-202	針杆下套	BUSHING	1
04-11	81-203	針杆下套	BUSHING	1
04-12	81-236	護針連杆軸前套	BUSHING	1
04-13	81-237	護針連杆軸后套	BUSHING	1
04-14	81-256	抬壓腳軸套	BUSHING	1
04-15	81-716	下軸左套	BUSHING	1
04-16	81-717	下軸右套	BUSHING	1
04-17	81-718	后拖輪左套	BUSHING	1
04-18	71-720	下軸中套	BUSHING	2
04-19	81-735	彎針軸套	BUSHING	2
04-20	81-753	牙架軸套	BUSHING	2
04-21	87-661	內六角螺釘	BOLT	4
04-22	94-214	油封	OIL SEAL	2
04-23	23-296	油封	PLUG	1
04-24	94-231	油封	OIL SEAL	1

5. 針杆部分 / NEEDLE BAR MECHANISM




REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q' TY
05-01	11-704	針杆	NEEDLE BAR	1
05-02	11-713	針杆	NEEDLE BAR	1
05-03	11-720	針杆	NEEDLE BAR	1
05-04	23-195	O型圈	O-RING	1
05-05	23-341	針杆連杆銷油綫	FELT	2
05-06	23-383	油綫	FELT	1
05-07	61-711	球接頭	CONNECTION ROD BALL	1
05-08	63-713	銅連杆	BALL JOINT	1
05-09	65-302	雙頭拉杆	CONNECTING BAR	1
05-10	66-111	針杆連杆	CONNECTING LINK	1
05-11	69-105	杠杆	NEEDLE LEVER E	1
05-12	69-120	止擺扎頭	GUIDE	1
05-13	71-432	針杆連杆銷	FEED ROCKER LINK PIN	2
05-14	71-933	針杆杠杆軸	NEEDLE LEVER STUD	1
05-15	73-113	針杆接頭	NEEDLE BAR CLAMP	1
05-16	73-115	針杆接頭	NEEDLE BAR CLAMP	1
05-17	75-674	墊圈	WASHER	1
05-18	81-113	針杆杠杆套	BUSHING	1
05-19	81-412	針杆杠杆軸后套	BUSHING	1
05-20	84-365	螺釘	SCREW	1
05-21	84-366	螺釘	SCREW	1
05-22	84-564	螺釘	SCREW	1
05-23	84-567	螺釘	SCREW	3
05-24				
05-25	85-181	螺釘	SCREW	1
05-26	86-741	螺母	NUT	1
05-27	86-742	螺母	NUT	1
05-28	87-113	內六角螺釘	BOLT	1
05-29	87-172	內六角螺釘	SCREW	1
05-30	87-225	內六角螺釘	BOLT	1
05-31	87-242	螺釘	SCREW	2
05-32	60-3700	連杆組件	CONNECTING ROD ASS'Y	1
05-33	75-332	墊圈	WASHER	1
05-34	69-1050-2	針杆杠杆組件	NEEDLE LEVER (WITH BUSHING)	1

6. 下軸部件 / CRANKSHAFT MECHANISM




REF.NO.序號	圖號	名 稱	DESCRIPTION	Q'TY
06-01	2	O型圈	O-RING	1
06-02	25	油綫	FELT	4-5
06-03	23-384	油氈	FELT	1
06-04	31-155	蝸杆	OIL PUMP ARM	1
06-05	51-017	針距調節塊	ADJUSTING BLOCK	1
06-06	51-031	蓋板	PLATE	1
06-07	61-528	偏心輪	LOOPER ECENTRIC	1
06-08	61-77	球接頭	LOOPER DRIVING ECCENTRIC	1
06-09	63-510	護針銅連杆	CONNECTING ROD	1
06-10	63-621	銅連杆	BALL JOINT	1
06-11	69-141	平衡塊	BALANCE WEIGHT	1
06-12	69-216	帶輪	PULLEY	1
06-13	69-305	下軸承蓋	FLANGE	1
06-14	71-612	前護針傳動軸	LOOPER DRIVING SHAFT	1
06-15	71-794	下軸前節	MAIN SHAFT	1
06-16	71-795	下軸前節	MAIN SHAFT	1
06-17	71-894	下軸后節	CRANK SHAFT (31)	1
06-18	71-895	下軸后節	CRANK SHAFT (34)	1
06-19	75-107	擋圈	COLLAR	1
06-20	75-327	墊圈	WASHER	1
06-21	75-329	墊圈	WASHER	1
06-22	75-332	墊圈	WASHER	1
06-23	75-452	墊圈	WASHER	1
06-24	75-673	墊圈	WASHER	1
06-25	84-383	螺釘	SCREW	1
06-26	84-568	螺釘	SCREW	2
06-27	84-635	螺釘	SCREW	2
06-28	84-661	螺釘	SCREW	4
06-29	85-212	內六角螺釘	BOLT	1
06-30	87-017	調節螺釘	BOLT	1
06-31	87-177	內六角螺釘	BOLT	3
06-32	87-172	內六角螺釘	SCREW	9
06-33	87-274	內六角螺釘	SCREW	2
06-34	87-242	內六角螺釘	SCREW	2
06-35	93-264	卡簧	RING	1
06-36	60-3760	連杆組件	CONNECTING ROD ASS'Y	1
06-37	70-0370	下軸組件	CRANK SHAFT ASS'Y (31)	1
06-38	70-0270	下軸組件	CRANK SHAFT ASS'Y (34)	1

7. 送布機構 / FEED MECHANISM




REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q'TY
07-01	23-341	油錢	FELT	2
07-02	55-041	牙架擺動座	SINGLE FEED ROCKER ARM	1
07-03	55-051	送布牙架支座	FEED DOG HOLDER	1
07-04	55-176	牙架	FEED ROCKER	1
07-05	61-322	抬牙凸輪	FEED ECCENTRIC	1
07-06	63-232	抬牙連杆	ECCENTRIC LINK	1
07-07	63-353	送布曲軸	FEED ROCKER LINK	1
07-08	67-311	送布擺杆	FEED ROCKER ARM	1
07-09	71-431	銷	PIN	1
07-10	71-432	抬牙連杆銷	FEED ROCKER LINK PIN	1
07-11	71-531	擺動座銷	SHAFT	1
07-12	71-642	牙架擺動銷	FEED ROCKER ARM SHAFT	1
07-13	75-139	擋圈	COLLAR	1
07-14	75-235	隔套	ROLLER	1
07-15	75-381	墊圈	WASHER	1
07-16	55-155	牙架	FEED ROCKER	1
07-17	75-675	墊圈	WASHER	2
07-18	84-176	調節螺釘	SCREW	1
07-19	84-177	調節螺釘	SCREW	1
07-20	84-366	螺釘	SCREW	3
07-21	84-464	螺釘	SCREW	1
07-22	84-588	螺釘	SCREW	1
07-23	55-156	牙架	FEED ROCKER	1
07-24	86-501	螺母	NUT	1
07-25	87-245	內六角螺釘	BOLT	1
07-26	87-113	內六角螺釘	BOLT	2
07-27	87-181	內六角螺釘	SCREW	2
07-28	87-252	內六角螺釘	BOLT	1
07-29	87-254	內六角螺釘	SCREW	1
07-30	91-270	滾針軸承	BEARING	1
07-31	91-406	滾針軸承	BEARING	1
07-32	93-261	卡簧	C-RING	1
07-33	93-406	卡簧	C-RING	1
07-34	60-0900	抬牙連杆組件	ECCENTRIC LINK ASS'Y	1
07-35	63-3530-2	送布柄組件	FEED ROCKER LINK ASS'Y	1

8. 彎針部件 / LOOPER MECHANISM




REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q' TY
08-01	18-722	機針導線器支架	NEEDLE GUTDE BRACKET	1
08-02	18-725	機針導線器	NEEDLE GUIDE	1
08-03	19-289	彎針曲柄	LOOPER ROCKER	1
08-04	19-290	彎針座	LOOPER HOLDER	1
08-05	19-292	擋圈	COLLAR	1
08-06	23-341	油綫	FELT	1
08-07	49-139	打綫凸輪	LOOPER THREAD TAKE-UP CAM	1
08-08	61-312	彎針凸輪	LOOPER AVOID ECCENTRIC	1
08-09	61-513	球接頭	CONNECTING BALL	2
08-10	63-232	彎針連杆	ECCENTRIC LINK	1
08-11	63-811	銅連杆	BALL JOINT	1
08-12	63-812	銅連杆	BALL JOINT	1
08-13	65-435	螺杆	CONNECTING BAR	1
08-14	67-132	彎針曲柄	LOOPER AVOID LEVER	1
08-15	67-229	彎針球連杆曲柄	LOOPER DRIVING LEVER	1
08-16	71-431	銷	PIN	1
08-17	71-561	彎針軸	LOOPER HOLDER SHAFT	1
08-18	71-901	彎針座軸	TAPERD PIN	1
08-19	75-114	擋圈	COLLAR	1
08-20	75-139	擋圈	COLLAR	1
08-21	75-372	墊圈	WASHER	1
08-22	75-401	墊圈	WASHER	1
08-23	75-452	墊圈	WASHER	1
08-24	75-527	彈簧墊圈	SPRING WASHER	1
08-25	75-552	墊圈	WASHER	1
08-26	75-675	墊圈	WASHER	1
08-27	81-401	擋圈	BUSHING	1
08-28	84-362	螺釘	SCREW	1
08-29	84-366	螺釘	SCREW	1
08-30	84-374	螺釘	SCREW	1
08-31	84-511	螺釘	SCREW	1
08-32	84-521	螺釘	SCREW	3
08-33	84-635	螺釘	SCREW	4
08-34	84-711	螺釘	SCREW	2
08-35	84-718	螺釘	SCREW	2
08-36	84-767	螺釘	SCREW	1
08-37	86-411	螺母	NUT	1
08-38	86-412	螺母	NUT	1
08-39	86-501	螺母	NUT	2
08-40	87-173	內六角螺釘	BOLT	1
08-41	87-181	螺釘	SCREW	2
08-42	87-213	內六角螺釘	BOLT	1
08-43	87-245	內六角螺釘	BOLT	1
08-44	87-254	螺釘	SCREW	1
08-45	91-406	滾子軸承	BEARING	1
08-46	93-406	卡簧	C-RING	1
08-47	60-0800	抬牙連杆組件	ECCENTRIC LINK ASS'Y	1
08-48	10-9280	彎針座組件	LOOPER HOLDER ASS'Y	1
08-49	60-3920	銅連杆組件(左)	CONNECTING ROD ASS'Y (LEFT)	1
08-50	60-3910	銅連杆組件(右)	CONNECTING ROD ASS'Y (RIGHT)	1
08-51	87-252	內六角螺釘	BOLT	1

9. 壓脚部件 / PRESSER FOOT MECHANISM




REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q'TY
09-01				
09-02	7	壓杆	PRESSER BAR (L)	1
09-03	75-100	墊圈	WASHER	1
09-04	77-509	限位塊	BRACKET	1
09-05	77-107	抬壓脚曲柄	CONNECTING PLATE	1
09-06	77-109	抬壓脚前杠杆	LIFTER LEVER SPRING SUPPORTER	1
09-07	77-116	抬壓脚拉杆	LIFTER LEVER CONNECTING BAR	1
09-08	77-113	抬壓脚吊板	PLATE	1
09-09	77	松綫曲柄	BRACKET	1
09-10	77-164	松綫軸	SHAFT	1
09-11	77-165	松綫軸套	PIPE	1
09-12	77-516	壓杆滑塊座	GUIDE	1
09-13	77-517	壓杆滑塊	PRESSER BAR GUIDE	1
09-14	77-816	抬壓脚杠杆	PRESSER FOOT LIFTER LEVER	1
09-15	79-121	壓脚調壓簧	PRESSER BAR SPRING	1
09-16	79-550	扭簧	SPRING	1
09-17	84-561	螺釘	SCREW	2
09-18	84-562	螺釘	SCREW	1
09-19	84-563	螺釘	SCREW	1
09-20	84-581	螺釘	SCREW	1
09-21				
09-22	85-201	軸位螺釘	SCREW	1
09-23	87-004	壓杆調壓螺釘	SCREW	1
09-24	87-112	內六角螺釘	BOLT	2
09-25	84-813	螺釘	SCREW	1
09-26	87-252	內六角螺釘	BOLT	2
09-27	88-003	螺母	NUT	1
09-28	93-611	開口銷	PIN	2
09-29	77-818	抬壓脚杠杆	PRESSER FOOT LIFTER LEVER	1
09-30	86-411	螺母	NUT	1
09-31	87-177	內六角螺釘	BOLT	2

10. 潤滑部件 / LUBRICATION MECHANISM




REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q' TY
10-01	17-8010-G	銷	PIN	1
10-02	23-120	密封墊	GASKET	4
10-03	23-160	密封墊	SEAL WASHER	3
10-04	23-304	油封	SEAL	1
10-05	23-363	回油氈	FELT	1
10-06	23-451	油盤墊	GASKET	1
10-07	23-514	油封墊	JOINT SEAL	4
10-08	31-364	回油接頭	JOINT	1
10-09	30-0120	油泵組件	PUMP ASS'Y	1
10-10	31-151	油泵體	PUMP HOUSING	1
10-11	31-152	傳動軸	PUMP SHAFT	1
10-12	31-153	安裝板	PALTE	1
10-13	31-154	下蓋板	PUMP REAR PLATE	1
10-14	31-156	過濾網	PUMP MESH	1
10-15	31-157	過濾網夾	CLAMP	1
10-16	31-270	油盤	OIL TANK	1
10-17	31-271	濾油網	OIL FILTER SCREW	1
10-18	31-314	連接頭	JOINT	1
10-19	75-536	墊圈	WASHER	4
10-20	31-702	蝸輪	PUMP GEAR	1
10-21	31-705	外輪	OUTER ROTER	1
10-22	31-707	內輪	INNER ROTER	1
10-23	35-122	機座供油組件	PIPE	1
10-24	35-361	三通連接頭	JOINT	6
10-25	35-362	通油螺釘	JOINT SCREW	1
10-26	35-413	油管夾	CLAMP	7
10-27				
10-28	39-133	油管板	PIPE SUPPORT C	1
10-29	39-216	油量指示鏡	OIL GAUGE	1
10-30	75-185	墊圈	COLLAR	1
10-31	30-0121	油泵組件	PUMP ASS'Y	1
10-32	75-452	墊圈	WASHER	2
10-33	87-010	螺釘	SCREW	1
10-34	84-367	螺釘	SCREW	2
10-35	87-287	內六角螺釘	BOLT	1
10-36	87-252	內六角螺釘	BOLT	2
10-37	87-173	內六角螺釘	BOLT	4
10-38	35-528	內六角螺釘	BOLT	2
10-39	87-123	內六角螺釘	BOLT	3
10-40	87-129	內六角螺釘	BOLT	3
10-41	87-140	內六角螺釘	BOLT	1
10-42	87-183	內六角螺釘	BOLT	2
10-43	84-363	螺釘	SCREW	1
10-44	87-254	螺釘	SCREW	1
10-45	87-311	螺釘	SCREW	1
10-46	88-137	螺母	NUT	1
10-47	35-246	機頭供油組件	PIPING	1
10-48	35-317	油管	TUBE	2
10-49	35-318	油管	TUBE	1
10-50		油管		
10-51	35-322	油管	TUBE	1
10-52	35-315	油管	TUBE	1
10-53	35-343	油管	TUBE	1
10-54	31-2700-2	油盤組件	OIL TANK ASS'Y	1

11. 后拖輪部件(P, PMD) / REAR PULLER MECHANISM (P, PMD)




REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q' TY
11-01	01-103	軸套	SLEEVE	2
11-02	02-116	波形墊圈	WAVE WASHER	1
11-03	02-117	蓋板	PLATE	1
11-04	02-122	主動軸內套	HOUSING	1
11-05	02-189	主動輪	REAR PULLER (SMOOTH)	1
11-06	02-251	后拖輪支架	REAR PULLER BRACKET	1
11-07	02-263	擺動板	CONNECTING PLATE	1
11-08	02-266	止擺塊	PLATE	1
11-09	02-488	主動輪	REAR PULLER GEAR	1
11-10	02-489	從動輪	REAR PULLER GEAR	1
11-11	02-301	主動輪	REAR PULLER	1
11-12	71-443	從動輪	SHAFT	1
11-13	71-651	從動輪軸	REAR PULLER SHAFT (LOWER)	1
11-14	71-921	止擺軸	PULLER GUIDE PIN	1
11-15	75-372	墊圈	WASHER	1
11-16	75-451	墊圈	WASHER	1
11-17	75-519	墊圈	WASHER	1
11-18	79-551	彈簧墊片	PULLER PLATE SPRING	1
11-19	81-321	主動輪右套	BUSHING	1
11-20	81-322	主動輪左套	BUSHING	1
11-21	81-323	滑套	BUSHING	1
11-22	84-162	螺釘	SCREW	6
11-23	84-463	螺釘	SCREW	2
11-24	84-573	螺釘	SCREW	1
11-25	87-214	內六角螺釘	BOLT	1
11-26	87-113	內六角螺釘	BOLT	2
11-27	87-129	內六角螺釘	BOLT	1
11-28	87-181	內六角螺釘	SCREW	1
11-29	87-225	內六角螺釘	BOLT	1
11-30	88-179	螺釘	NUT	2
11-31	91-405	滾針軸承	BEARING	2
11-32	93-221	卡簧	E-RING	1
11-33	00-0421	42齒后拖輪組件	42 TEETH PULLER ASS'Y	1
11-34	00-2002	平滑后拖輪組件	SMOOTH PULLER ASS'Y	1

12. 后拖輪連接部件 / REAR PULLER MECHANISM




REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q' TY
12-01	02-112	波形墊圈	WASHER	1
12-02	02-204	后拖輪提升塊	BRACKET	1
12-03	02-205	拉板	PLATE	1
12-04	02-219	后拖輪提升杠杆	LEVER	1
12-05	02-408	后拖輪提升扳手	LEVER	1
12-06	61-208	偏心凸輪	PULLER DRIVING ECCENTRIC	1
12-07	61-714	球接頭	CONNECTING ROD BALL	1
12-08	61-810	球接頭	CONNECTING ROD BALL	1
12-09	63-208	銅連杆	CONNECTING LINK	1
12-10	63-711	銅連杆	BALL JOINT	1
12-11	63-810	銅連杆	BALL JOINT	1
12-12	65-302	雙頭連杆	CONNECTING BAR	1
12-13	67-171	后拖輪前曲柄	PULLER DRIVING LEVER (FRONT)	2
12-14	67-172	后拖輪后曲柄	PULLER DRIVING LEVER (REAR)	1
12-15	71-450	后拖輪堅軸	SHAFT	1
12-16	71-691	后拖輪擺動軸	PULLER DRIVING SHAFT	1
12-17	71-726	銷軸	SHAFT	1
12-18	75-112	擋圈	COLLAR	1
12-19	75-211	滾柱	COLLAR	1
12-20	75-247	滾柱	ROLLER	1
12-21	75-332	墊圈	WASHER	1
12-22	75-458	墊圈	WASHER	2
12-23	75-491	墊圈	WASHER	1
12-24	75-493	滾柱	COLLAR	1
12-25	75-515	墊圈	WASHER	1
12-26	75-520	墊圈	WASHER	2
12-27	75-552	墊圈	WASHER	1
12-28	77-419	銷子	PIN	2
12-29	77-420	后拖輪提升曲柄	PLATE	1
12-30	77-425	拉杆	PLATE	1
12-31	79-425	壓脚調壓彈簧	SPRING	1
12-32	84-567	螺釘	SCREW	2
12-33	84-581	螺釘	SCREW	1
12-34	84-582	螺釘	SCREW	1
12-35	84-635	螺釘	SCREW	2
12-36	85-671	軸位螺釘	SCREW	1
12-37	86-411	螺母	NUT	1
12-38	86-501	螺母	NUT	1
12-39	86-741	螺母	NUT	1
12-40	86-742	螺母	NUT	1
12-41	87-171	內六角螺釘	BOLT	1
12-42	87-172	內六角螺釘	SCREW	3
12-43	87-173	內六角螺釘	BOLT	1
12-44	87-214	內六角螺釘	BOLT	1
12-45	87-225	內六角螺釘	BOLT	2
12-46	87-242	內六角螺釘	SCREW	1
12-47	87-254	內六角螺釘	SCREW	2
12-48	87-285	內六角螺釘	BOLT	1
12-49	87-287	內六角螺釘	BOLT	1
12-50	87-291	內六角螺釘	BOLT	1
12-51	87-754	調壓螺釘	SCREW	1
12-52	88-146	螺母	NUT	1
12-53	88-157	螺母	NUT	1
12-54	93-203	卡簧	E-RING	1
12-55	93-205	卡簧	E-RING	2
12-56	93-222	卡簧	E-RING	1
12-57	93-258	卡簧	SNAP RING	1

13. 前拖輪部件 / METERING DEVICE MECHANISM




REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q'TY
13-01	01-103	軸套	SLEEVE	2
13-02	01-111	支架	BRACKET	1
13-03	01-113	前拖輪蓋	CLUTCH DRIVING COLLAR	1
13-04	01-116	前蓋板	PLATE	1
13-05	01-132	上滾輪	PULLER	1
13-06	01-134	下滾輪	LOWER ROLLER	1
13-07	01-136	滾輪固定器	ROLLER HOLDER	2
13-08	01-138	樞軸固定器	PIVOT SHAFT HOLDER	2
13-09	01-141	橡膠緊綫器	RUBBER TIGHTENER	1
13-10	01-143	滾輪控制器	ROLLER CONTROLER	1
13-11	01-145	杠杆	LEVER	1
13-12	01-146	蓋板	COVER	1
13-13	01-147	銷	PIN	1
13-14	01-152	導向器	GUIDE	1
13-15	05-954	連接塊	ROD	1
13-16	23-341	油綫	FELT	1
13-17	65-333	滾輪連接螺絲	PULLER CONNECTING BAR	1
13-18	66-131	連杆接頭	CONNECTING LINK	1
13-19	67-180	擺杆	PULLER CONNECTING LEVER	1
13-20	71-227	銷	PIN	1
13-21	71-350	軸	SHAFT	1
13-22	71-361	樞軸(大)	PIVOT SHAFT (LARGE)	2
13-23	71-362	樞軸(小)	PIVOT SHAFT (SMALL)	1
13-24	71-432	進料搖杆銷	FEED ROCKER LINK PIN	1
13-25	75-446	墊圈	WASHER	1
13-26	75-451	墊圈	WASHER	2
13-27	75-468	墊圈	WASHER	2
13-28	75-480	墊圈	WASHER	1
13-29	75-552	墊圈	WASHER	3
13-30	79-171	彈簧	SPRING	1
13-31	81-125	軸套	BUSHING	2
13-32	84-162	螺釘	SCREW	6
13-33	84-314	內六角螺釘	SCREW	1
13-34	84-813	螺釘	SCREW	2
13-35	86-701	螺母	NUT	1
13-36	87-006	軸位螺釘	SCREW	1
13-37	87-092	內六角螺釘	BOLT	2
13-38	87-129	內六角螺釘	BOLT	2
13-39	87-177	內六角螺釘	BOLT	2
13-40	87-181	內六角螺釘	SCREW	6
13-41	87-203	內六角螺釘	BOLT	1
13-42	87-253	內六角螺釘	SCREW	1
13-43	87-254	螺釘	SCREW	1
13-44	87-456	調壓螺釘	SCREW	1
13-45	88-161	螺母	NUT	1
13-46	88-166	螺母	NUT	1
13-47	88-456	調壓螺母	NUT	1
13-48	91-405	滾針軸承	BEARING	2
13-49	93-200	卡簧	E-RING	1
13-50	00-1401	前拖輪機構組件	METERING DEVICE ASS'Y	1

14. BK専用部品(1) / MODEL BK EXCLUSIVE PARTS (1)




REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q'TY
14-01	07-295	定位塊	GUIDE PLATE	1
14-02	07-388	輔助送布牙支架	BRACKET	1
14-03	07-389	輔助送布牙支架	BRACKET	1
14-04	07-3950-A	輔助壓腳	PRESSER FOOT BOTTOM	1
14-05	07-3950-D	銷	PIN	1
14-06	07-3950-B	輔助壓腳(右)	GUIDE (R)	1
14-07	07-3950-C	輔助壓腳(左)	GUIDE (L)	1
14-08	07-722	輔助支架	SUPPORT BRACKET	1
14-09	07-726	送布牙	FEED DOG	1
14-10	07-728	輔助針板	PLATE	1
14-11	07-750	支架上罩板	GUIDE COVER	1
14-12	14-066	針板座	NEEDLE PLATE SUPPORT BRACKET	1
14-13	14-067	針板座	NEEDLE PLATE SUPPORT BRACKET	1
14-14	21-227	壓板	SLIDE COVER	1
14-15	21-393	上罩殼	UPPER COVER	1
14-16	21-394	上罩殼	UPPER COVER	1
14-17	55-156	牙架	FEED ROCKER	1
14-18	75-456	墊圈	WASHER	1
14-19	71-795	下軸前節	MIN SHAFT	1
14-20	71-894	下軸后節	CRANK SHAFT	1
14-21	75-152	擋圈	COLLAR	1
14-22	75-381	墊圈	WASHER	1
14-23	75-519	墊圈	WASHER	1
14-24	79-142	彈簧	SPRING	1
14-25	79-801	壓簧	SPRING	1
14-26	84-161	螺釘	SCREW	2
14-27	84-163	螺釘	SCREW	2
14-28	84-363	螺釘	SCREW	2
14-29	84-364	螺釘	SCREW	4
14-30	84-464	螺釘	SCREW	1
14-31	84-566	螺釘	SCREW	1
14-32	84-571	螺釘	SCREW	1
14-33	84-761	螺釘	SCREW	5
14-34	84-763	螺釘	SCREW	2
14-35	84-862	螺釘	SCREW	1~2
14-36	86-501	螺母	NUT	1
14-37	87-181	螺釘	SCREW	2
14-38	87-252	內六角螺釘	BOLT	2
14-39	87-292	調節螺釘	SCREW	1
14-40	93-720	銷	PIN	1
14-41	93-727	銷	PIN	1
14-42	71-895	下軸后節	CRANK SHAFT	1
14-43	07-3950-2	輔助壓腳組件	PRESSER FOOT ASS'Y	1
14-44	55-053	送布牙安裝支架	FEED DOG HOLDER	1

15. BK専用部品(2) / MODEL BK EXCLUSIVE PARTS (2)







REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q'TY
15-01	07-701	連杆	CONNECTING BAR	1
15-02	07-702	上切刀(左)	UPPER KNIFE (L)	1
15-03	07-703	上切刀(右)	UPPER KNIFE (R)	1
15-04	07-705	上切刀安裝支架(右)	UPPER KNIFE BRACKET (R)	1
15-05	07-706	上切刀擺動軸	SHAFT	1
15-06	07-707	下切刀	LOWER KNIFE	2
15-07	07-721	下切刀驅動曲柄	LEVER	1
15-08	07-733	輔助墊板	PLATE	1
15-09	07-739	切刀支架	JOINT BRACKET	1
15-10	07-742	支架	BASE BRACKET	1
15-11	07-743	下切刀安裝支架(左)	LOWER KNIFE HOLDER (L)	1
15-12	07-744	下切刀安裝支架(右)	LOWER KNIFE HOLDER (R)	1
15-13	07-746	切刀左護板	CHIP GUIDE COVER (L)	1
15-14	07-747	切刀右護板	CHIP GUIDE COVER (R)	1
15-15	07-748	安裝支架(左)	UPPER KNIFE BRACKET (L)	1
15-16	07-749	軸套	BUSHING	1
15-17	07-751	導板	GUIDE PLATE	1
15-18	07-752	螺釘銷	PIN	1
15-19	61-255	偏心輪	ECCENTRIC	1
15-20	61-841	球接頭	JOINT BALL	1
15-21	63-211	前切刀連杆	ECCENTRIC LINK	1
15-22	63-811	銅連杆	BALL JOINT	1
15-23				
15-24	75-254	蓋板	PLATE	1
15-25	75-401	墊圈	WASHER	1
15-26	75-458	墊圈	WASHER	2
15-27	75-468	墊圈	WASHER	2
15-28	79-148	彈簧	SPRING	1
15-29	81-704	軸套	BUSHING	2
15-30	84-161	螺釘	SCREW	4
15-31	84-362	螺釘	SCREW	2
15-32	84-521	內六角螺釘	SCREW	2
15-33	84-635	螺釘	SCREW	2
15-34	84-571	螺釘	SCREW	2
15-35	84-574	螺釘	SCREW	2
15-36	84-727	內六角螺釘	SCREW	2
15-37	84-192	螺釘	SCREW	2
15-38	84-812	螺釘	SCREW	2
15-39	86-411	螺母	NUT	2
15-40	87-113	內六角螺釘	BOLT	2
15-41	87-177	內六角螺釘	BOLT	2
15-42	87-181	螺釘	SCREW	2
15-43	88-166	螺母	NUT	1
15-44	91-411	滾針軸承	BEARING	1
15-45	60-1330	連杆組件	ECCENTRIC LINK ASS'Y	1
15-46	60-3830	銅連杆組件	CONNECTING ROD ASS'Y	1

16. EHD専用部品 / MODEL EHD EXCLUSIVE PARTS




REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q' TY
16-01	14-065	針板座	NEEDLE PLATE SUPPORT BRACKET	1
16-02				
16-03	21-783	護板	COVER	1
16-04	21-837	上罩殼	CLOTH PLATE	1
16-05	21-838	前鉛蓋	FRONT COVER	1
16-06	21-839	前鉛蓋固定板	RULER PLATE	1
16-07	21-840	前罩殼	FRONT BASE COVER	1
16-08	23-504	油封	PLUG	1
16-09	23-512	防震墊	CUSHION RUBBER	1
16-10	25-226	固定支架	HINGE	1
16-11	25-503	螺釘	SCREW	1
16-12	25-517	螺釘	SCREW	1
16-13	26-553	定規	GUIDE	1
16-14				
16-15	75-528	波形墊圈	WASHER	1
16-16	79-801	壓簧	SPRING	1
16-17	79-803	壓簧	SPRING	1
16-18	79-922	彈簧墊圈	SPRING	2
16-19	84-117	螺釘	SCREW	2
16-20	84-361	螺釘	SCREW	2
16-21	84-574	螺釘	SCREW	2
16-22	84-706	螺釘	SCREW	1
16-23	84-761	螺釘	SCREW	3
16-24	84-762	螺釘	SCREW	4
16-25	84-862	螺釘	SCREW	2
16-26	85-182	螺釘	SCREW	2
16-27	86-266	螺母	NUT	1
16-28	87-266	螺釘	SCREW	1
16-29	87-285	內六角螺釘	BOLT	2
16-30	87-286	螺釘	SCREW	1

17. 挑綫機構(1701EHD) / THREAD TENSION MECHANISM (1701EHD)




REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q'TY
17-01	23-324	氈墊圈	FELT	2
17-02	41-101	夾綫螺釘母	THREAD TENSION NUT	2
17-03	41-105	夾綫螺母止動板	SPRING POST	2
17-04	41-107	夾綫外殼	SPRING CUP	2
17-05	41-110	夾綫板	TENSION DISC	4
17-06	41-113	松綫頂板	TENSION POST SUPPORT	1
17-07	41-118	過綫板	THREAD EYELET	2
17-08	41-119	過綫板	THREAD EYELET	2
17-09	41-121	夾綫器安裝架	TENSION POST HOLDER	1
17-10	41-132	墊圈	COLLAR	1
17-11	41-510	夾綫螺釘	SCREW STUD	2
17-12	41-701	彈簧(強)	SPRING (HEAVY)	1
17-13	41-702	彈簧(弱)	SPRING (LIGHT)	1
17-14	43-112	銷	PIN	1
17-15	43-333	導綫器	THREAD GUIDE	1
17-16	43-335	卡簧	LOOPER THREAD RETAINER WIRE	1
17-17	43-339	導綫器安裝支架	BRACKET	1
17-18	43-341	支架	GUIDE PLATE	1
17-19	43-437	下過綫	THREAD EYELET	2
17-20	45-109	上過綫板	THREAD EYELET	1
17-21	45-129	挑綫杆	THREAD EYELET	1
17-22	45-139	針杆挑綫杆	THREAD EYELET	1
17-23	45-429	針杆擋綫杆	THREAD TAKE-UP PLATE	1
17-24	45-439	機針上過綫板	THREAD EYELET	1
17-25	45-440	機針下過綫板	THREAD EYELET	1
17-26	47-171	下過綫板	THREAD EYELET	3
17-27	71-191	銷	PIN	2
17-28	75-455	墊圈	WASHER	2
17-29	75-456	墊圈	WASHER	1
17-30	84-161	螺釘	SCREW	4
17-31	84-162	螺釘	SCREW	1
17-32	84-361	螺釘	SCREW	2
17-33	84-374	螺釘	SCREW	1
17-34	84-764	螺釘	SCREW	1
17-35	86-411	螺母	NUT	1
17-36	87-097	螺釘	SCREW	1
17-37	87-113	內六角螺釘	BOLT	1
17-38	87-177	內六角螺釘	BOLT	1
17-39	87-293	螺釘	SCREW	4
17-40	87-272	螺釘	SCREW	1
17-41	40-3700	彎針過綫組件	LOOPER THREAD EYELET ASS'Y	1

18. 1701EHD専用部品 / MODEL 1701EHD EXCLUSIVE PARTS





REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q' TY
18-01	18-726	機針導線器	NEEDLE GUIDE	1
18-02	23-341	油錢	FELT	3
18-03	55-055	送布牙架支架	FEED DOG HOLDER	1
18-04	55-175	牙架	FEED ROCKER	1
18-05	61-313	抬牙凸輪	LOOPER AVOID ECCENTRIC	1
18-06	61-325	抬牙凸輪	FEED ECCENTRIC	1
18-07	63-232	抬牙連杆	ECCENTRIC LINK	2
18-08	63-352	送布曲柄	FEED ROCKER LINK	1
18-09	63-621	銅連杆	BALL JOINT	1
18-10	67-312	送布擺杆	FEED ROCKER ARM	1
18-11	71-431	銷	PIN	3
18-12	71-774	下軸前節	MAIN SHAFT	1
18-13	71-878	下軸后節	CRANK SHAFT	1
18-14	75-235	隔套	ROLLER	1
18-15	84-366	螺釘	SCREW	1
18-16	84-568	螺釘	SCREW	2
18-17	87-181	內六角螺釘	SCREW	2
18-18	87-252	內六角螺釘	BOLT	1
18-19	87-254	內六角螺釘	SCREW	2
18-20	91-270	滾針軸承	BEARING	1
18-21	91-406	滾針軸承	BEARING	1
18-22	93-406	卡簧	C-RING	1
18-23	60-1120	抬牙連杆組件	ECCENTRIC LINK ASS'Y	1
18-24	60-1230	抬牙連杆組件	ECCENTRIC LINK ASS'Y	1
18-25	70-0190	下軸組件	CRANK SHAFT ASS'Y	1
18-26	60-7200	送布擺杆組件	FEED ROCKER ARM SET	1


19. 挑綫機構(1702EHD) / THREAD TENSION MECHANISM (1702EHD)



A




B




REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q'TY
19-01	23-324	氈墊圈	FELT	2
19-02	41-101	夾錢螺母	THREAD TENSION NUT	2
19-03	41-105	夾錢螺母止動板	SPRING POST	2
19-04	41-107	夾錢外殼	SPRING CUP	2
19-05	41-110	夾錢板	TENSION DISC	4
19-06	41-113	松錢頂板	TENSION POST SUPPORT	1
19-07	41-118	過錢板	THREAD EYELET	4
19-08	41-119	過錢板	THREAD EYELET	4
19-09	41-121	夾錢器安裝板	TENSION POST HOLDER	1
19-10	41-510	夾錢螺釘	SCREW STUD	2
19-11	41-701	彈簧(強)	SPRING (HEAVY)	1
19-12	41-702	彈簧(弱)	SPRING (LIGHT)	1
19-13	43-104	導錢器	RETAINER UPPER	1
19-14	43-105	卡簧	GUIDE WIRE	1
19-15	43-112	銷	PIN	1
19-16	43-335	導錢管卡管	LOOPER THREAD RETAINER WIRE	1
19-17	43-339	夾錢器安裝支架	BRACKET	1
19-18	43-345	支架	GUIDE PLATE	1
19-19	43-437	下過錢	THREAD EYELET	2
19-20	45-099	上過錢板	THREAD EYELET	1
19-21	45-114	挑錢杆	THREAD EYELET	1
19-22	45-172	針杆挑錢杆	THREAD EYELET	1
19-23	45-429	針杆挑錢杆	THREAD TAKE-UP PLATE	1
19-24	45-439	機針上過錢板	THREAD EYELET	1
19-25	45-440	機針下過錢板	THREAD EYELET	1
19-26	47-172	下過錢板	THREAD EYELET	3
19-27	71-191	銷	PIN	2
19-28	75-455	墊圈	WASHER	2
19-29	75-456	墊圈	WASHER	1
19-30	84-161	螺釘	SCREW	5
19-31	84-162	螺釘	SCREW	1
19-32	84-361	螺釘	SCREW	2
19-33	84-374	螺釘	SCREW	1
19-34	86-411	螺母	NUT	2
19-35	87-097	螺釘	SCREW	1
19-36	87-113	內六角螺釘	BOLT	1
19-37	87-177	內六角螺釘	BOLT	1
19-38	87-293	螺釘	SCREW	4
19-39	87-272	螺釘	SCREW	1
19-40	40-3710	彎針過錢組件	LOOPER THREAD EYELET ASS'Y	1

20. 1702EHD専用部品 / MODEL 1702EHD EXCLUSIVE PARTS




REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q'TY
20-01	19-292	擋圈	COLLAR	1
20-02	19-318	彎針座	LOOPER HOLDER	1
20-03	23-341	油綫	FELT	3
20-04	55-055	送布牙底板	FEED DOG HOLDER	1
20-05	55-175	牙架	FEED ROCKER	1
20-06	61-313	彎針凸輪	LOOPER AVOID ECCENTRIC	1
20-07	61-325	彎針凸輪	FEED ECCENTRIC	1
20-08	61-823	球接頭	CONNECTING BALL	1
20-09	63-232	彎針連杆	ECCENTRIC LINK	2
20-10	63-352	送布曲柄	FEED ROCKER LINK	1
20-11	63-621	銅連杆	BALL JOINT	1
20-12	63-812	銅連杆	BALL JOINT	1
20-13	67-312	送布擺杆	FEED ROCKER ARM	1
20-14	71-431	銷	PIN	3
20-15	71-774	下軸前節	MAIN SHAFT	1
20-16	71-878	下軸后節	CRANK SHAFT	1
20-17	71-901	彎針座軸	TAPERD PIN	1
20-18	75-235	擋圈	ROLLER	1
20-19	75-452	墊圈	WASHER	1
20-20	75-453	墊圈	WASHER	1
20-21	81-401	擋圈	BUSHING	1
20-22	84-366	螺釘	SCREW	1
20-23	84-374	螺釘	SCREW	1
20-24	84-521	螺釘	SCREW	4
20-25	84-568	螺釘	SCREW	2
20-26	84-635	螺釘	SCREW	2
20-27	86-413	螺母	NUT	1
20-28	86-501	螺母	NUT	1
20-29	87-181	螺釘	SCREW	2
20-30	87-252	內六角螺釘	BOLT	1
20-31	87-254	螺釘	SCREW	2
20-32	91-270	滾針軸承	BEARING	1
20-33	91-406	滾針軸承	BEARING	1
20-34	93-406	卡簧	C-RING	1
20-35	10-9180	彎針座組件	LOOPER HOLDER ASS'Y	1
20-36	60-1120	拍牙連杆組件	ECCENTRIC LINK ASS'Y	1
20-37	60-1230	拍牙連杆組件	ECCENTRIC LINK ASS'Y	1
20-38	70-0190	下軸組件	CRANK SHAFT ASS'Y	1
20-39	60-7200	送布擺杆組件	FEED ROCKER ARM SET	1
20-40	60-3720	銅連杆組件	CONNECTING ROD ASS'Y (LEFT)	1

21. 綫架與臺板部件 / THREAD STAND AND TABLE



REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q' TY
21-01	21-045	臺板	TABLE	1
21-02	25-140	托板	SUPPORTING BOARD	2
21-03	31-163	防震墊	CUSHION RUBBER	4
21-04	80-751	內六角	BOLT	4
21-05	42-002	2針綫架	THREAD STANK ASSEMBLY FOR 2	1
21-06	42-716	6針綫架	THREAD STANK ASSEMBLY FOR 6	1
21-07	21-0450-1	臺板	TABLE	1
21-08	20-6030-0	帶導管組件	TAPE STANDS	1


22. 附件 / ACCESSORIES



REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q' TY
22-01	25-140	托板	MACHINE MOUNT BRACKET	2
22-02	28-611	大油壺	OIL	1
22-03	31-163	防震墊	CUSHION RUBBER	4
22-04	28-920	拉鏈組件	SHAIN	1
22-05	20-0020	附件	ACCESSORIES	1
22-06	80-751	螺釘	SCREW	4
22-07	28-464	T型扳手	T-WRENCH	1
22-08	28-452	螺絲刀	DRIVER (L)	1
22-09				
22-10	28-011	鑷子	TWEZERS	1
22-11	28-614	油壺	OILER	1
22-12	28-615	漏門	OIL FUNNEL	1
22-13	28-317	內六角扳手(1.5mm)	ALLEN KEY (1.5mm)	1
22-14	28-311	內六角扳手(2mm)	ALLEN KEY (2mm)	1
22-15	28-312	內六角扳手(2.5mm)	ALLEN KEY (2.5mm)	1
22-16	28-313	內六角扳手(3mm)	ALLEN KEY (3mm)	1
22-17	28-314	內六角扳手(5mm)	ALLEN KEY (5mm)	1
22-18	13-0140-6	機針UYx128GAS#14	NEEDLE UYx128GAS#14	1
22-19	13-0160-6	機針UYx128GAS#16	NEEDLE UYx128GAS#16	1
22-20	13-0110-6	機針UYx128GAS#11	NEEDLE UYx128GAS#11	1
22-21	13-2750-5	機針DR-2#25	NEEDLE DR-2#25	1
22-22	13-2800-6	機針UYx143GS#25	NEEDLE UYx143GS#25	1

23. 針位部件 / GAUGE PARTS


1702B, BK, PBK




REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q'TY
23-01	11-704	針杆	NEEDLE BAR	1
23-02	*	機針座	NEEDLE CLAMP	1
23-03	*	針板	NEEDLE PLATE	1
23-04	15-704	送布牙	FEED DOG	1
23-05	17-4430-A	壓腳柄	SHANK	1
23-06	17-4430-C	壓腳銷	SCREW	1
23-07	17-7600-E	導塊	GUIDE	2
23-08	*	壓腳底板	BOTTOM	1
23-09	18-702	護針	NEEDLE GUARD	1
23-10	18-705	護針	NEEDLE GUARD	1
23-11	19-712	彎針	LOOPER	1
23-12	45-255	針杆挑線	THREAD GUIDE	1
23-13	84-113	螺釘	SCREW	1
23-14	84-161	螺釘	SCREW	2
23-15	85-618	螺釘	SCREW	1
23-16	87-104	螺釘	SCREW	2
23-17	87-252	內六角螺釘	BOLT	1
23-18	84-382	螺釘	SCREW	1
23-19	84-464	螺釘	SCREW	2
23-20	75-455	墊圈	WASHER	2
23-21	*	夾帶卷邊龍頭	HOLDER	1
23-22	*	壓腳組件	PRESSER FOOT ASS'Y	1
23-23	84-368	螺釘	SCREW	2
23-24	45-549	針杆挑線	THREAD GUIDE	1
23-25	75-456	墊圈	WASHER	1
23-26	87-096	螺釘	SCREW	2

24. 針位部件 / GAUGE PARTS

1702P, PMD




1702MLH




REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q' TY
24-01	11-704	針杆	NEEDLE BAR	1
24-02	*	機針座	NEEDLE CLAMP	1
24-03	*	針板	NEEDLE PLATE	1
24-04	14-7210-A	針板爪	NAIL	1
24-05	*	針板	NEELE PLATE	1
24-06	15-321	送布牙	FEED DOG	1
24-07	*	送布牙	FEED DOG	1
24-08	17-4430-A	壓腳柄	SHANK	1
24-09	17-4430-C	壓腳銷	SCREW	1
24-10	*	壓腳底板	BOTTOM	1
24-11	17-7210-B	壓腳底板	BOTTOM	1
24-12	17-8190-A	壓腳柄	SHANK	1
24-13	17-8190-B	輔助壓腳	GUIDE BRACKET	2
24-14	17-8190-D	壓腳彈簧(左)	SPRING (LEFT)	1
24-15	17-8190-E	壓腳彈簧(右)	SPRING (RIGHT)	1
24-16	17-8190-F	彈簧	SPRING	1
24-17	17-8190-G	壓腳銷	PIN	1
24-18	18-702	護針	NEEDLE GUARD	1
24-19	19-712	彎針	LOOPER	1
24-20	19-351	彎針	LOOPER	1
24-21	45-549	機針過線	THREAD GUIDE	1
24-22	87-104	螺釘	SCREW	3
24-23	84-113	螺釘	SCREW	1
24-24	84-163	螺釘	SCREW	1
24-25	75-456	墊圈	WASHER	1
24-26	87-252	內六角螺釘	BOLT	1
24-27	87-113	螺釘	SCREW	1
24-28	84-464	螺釘	SCREW	2
24-29	17-8190-J	輔助壓腳導板	GUIDE PLATE	2
24-30	87-107	螺釘	SCREW	4
24-31	87-083	螺釘	SCREW	1
24-32	75-441	墊圈	WASHER	1
24-33	*	壓腳組件(MLH)	PRESSER FOOT ASS'Y	1
24-34	79-571	彈簧壓片	THREAD RETAINING SPRING	1
24-35	85-611	螺釘	SCREW	1
24-36	85-618	螺釘	SCREW	1
24-37	*	壓腳組件(P,PMD)	PRESSER FOOT ASS'Y	1

25. 針位部件 / GAUGE PARTS

1701EHD







1702EHD



REF.NO.序號	PART NO.圖號	名 稱	DESCRIPTION	Q' TY
25-01	11-713	針杆	NEEDLE BAR	1
25-02	11-720	針杆	NEEDLE BAR	1
25-03	12-718	機針座	NEEDLE CLAMP	1
25-04	14-717	針板	NEEDLE PLATE	1
25-05	14-718	針板	NEEDLE PLATE	1
25-06	15-710	送布牙	FEED DOG	1
25-07	15-718	送布牙	FEED DOG	1
25-08	17-7150-A	壓腳柄	SHANK	1
25-09	17-7180-B	壓腳底板	BOTTOM	1
25-10	17-7180-C	壓腳銷	PIN	1
25-11	17-7190-B	壓腳底板	BOTTOM	1
25-12	18-731	護針	NEEDLE GUARD	1
25-13	19-703	彎針	LOOPER	1
25-14	19-720	彎針	LOOPER	1
25-15	19-721	彎針	LOOPER	1
25-16	79-191	彈簧	SPRING	1
25-17	84-113	螺釘	SCREW	1
25-18	84-311	螺釘	SCREW	2
25-19	84-367	螺釘	SCREW	1
25-20	84-368	螺釘	SCREW	1
25-21	84-575	螺釘	SCREW	2
25-22	17-7190-1	壓腳組件(1702EHD)	PRESSER FOOT ASS'Y	1
25-23	17-7180-1	壓腳組件(1701EHD)	PRESSER FOOT ASS'Y	1

26. 針位部件一覽表 / GAUGE PARTS TABLE

型號 Model	針位 Gauge size	針棒 Needle Bar	針夾頭 Needle Holder	壓脚 Presser Foot Ass`Y	針板 Needle Plate	送布牙 Feed Dog	彎針夾頭 Looper Holder	彎針 Needle Guard	彎針 Looper				
													
1702B	3/16	11-704	12-2170-1	17-7420-1	14-743	15-704	19-315	18-702	19-712				
	7/32		12-2280-1	17-7520-1	14-753			18-705					
	1/4		12-2290-1	17-7620-1	14-763								
1702BK	3/16		12-2180-1	17-7420-1	14-743			18-702					
	7/32		12-2190-1	17-7520-1	14-753								
	1/4		12-2200-1	17-7620-1	14-763								
1702P 1702PMD	1/8		12-2150-1	17-6760-1	14-724	15-703		19-351					
	5/32		12-2160-1	17-6770-1	14-734	15-704							
	3/16		12-2170-1	17-6780-1	14-744								
	7/32		12-2280-1	17-6790-1	14-754	18-731		19-703					
	1/4		12-2290-1	17-6800-1	14-764	19-720							
1702MLH	1/8		12-2150-1	17-7210-1	14-721			15-321					
1701EHD		11-713		17-7180-1	14-718	15-718							
1702EHD	1/4	11-720	12-7180-1	17-7190-1	14-717	15-710	19-318		19-721				

目錄 1 / INDES 1

序號 REF.NO.	圖號 PART NO.	序號 REF.NO.	圖號 PART NO.	序號 REF.NO.	圖號 PART NO.	序號 REF.NO.	圖號 PART NO.	序號 REF.NO.	圖號 PART NO.	序號 REF.NO.	圖號 PART NO.
11-33	00-0421	15-13	07-746	08-02	18-725	17-01	23-324	10-17	31-271	03-13	41-702
13-50	00-1401	15-14	07-747	18-01	18-726	19-01	23-324	10-18	31-314	17-13	41-702
11-34	00-2002	15-15	07-748	25-12	18-731	05-05	23-341	10-08	31-364	19-12	41-702
11-01	01-103	15-16	07-749	08-03	19-289	06-02	23-341	02-23	31-438	03-14	41-721
13-01	01-103	14-11	07-750	08-04	19-290	07-01	23-341	10-20	31-702	21-05	42-002
13-02	01-111	15-17	07-751	08-05	19-292	08-06	23-341	10-21	31-705	21-06	42-716
13-03	01-113	15-18	07-752	20-01	19-292	13-16	23-341	10-22	31-707	19-13	43-104
13-04	01-116	20-35	10-9180	20-02	19-318	18-02	23-341	10-23	35-122	19-14	43-105
13-05	01-132	08-48	10-9280	24-20	19-351	20-03	23-341	10-47	35-246	17-14	43-112
13-06	01-134	05-01	11-704	25-13	19-703	10-05	23-363	10-52	35-315	19-15	43-112
13-07	01-136	23-01	11-704	23-11	19-712	05-06	23-383	10-48	35-317	17-15	43-333
13-08	01-138	24-01	11-704	24-19	19-712	06-03	23-384	10-49	35-318	03-15	43-335
13-09	01-141	05-02	11-713	25-14	19-720	01-12	23-427	10-51	35-322	17-16	43-335
13-10	01-143	25-01	11-713	25-15	19-721	10-06	23-451	10-53	35-343	19-16	43-335
13-11	01-145	05-03	11-720	22-05	20-0020	02-16	23-504	10-24	35-361	17-17	43-339
13-12	01-146	25-02	11-720	21-08	20-6030-0	16-08	23-504	10-25	35-362	19-17	43-339
13-13	01-147	25-03	12-718	21-01	21-045	02-17	23-512	10-26	35-413	17-18	43-341
13-14	01-152	22-20	13-0110-6	21-07	21-0450-1	16-09	23-512	10-38	35-528	03-16	43-344
12-01	02-112	22-18	13-0140-6	02-03	21-137	10-07	23-514	01-16	39-108	19-18	43-345
11-02	02-116	22-19	13-0160-6	02-04	21-227	01-13	24-052	10-28	39-133	03-17	43-346
11-03	02-117	22-21	13-2750-5	14-14	21-227	02-18	24-053	01-17	39-137	17-19	43-437
01-01	02-119	22-22	13-2800-6	01-02	21-273	21-02	25-140	10-29	39-216	19-19	43-437
11-04	02-122	02-01	14-030	01-03	21-275	22-01	25-140	01-18	39-234	03-18	43-519
11-05	02-189	02-02	14-064	01-04	21-276	02-19	25-226	17-41	40-3700	19-20	45-099
12-02	02-204	16-01	14-065	02-05	21-366	16-10	25-226	19-40	40-3710	03-19	45-101
12-03	02-205	14-12	14-066	14-15	21-393	02-20	25-503	03-42	40-3810	17-20	45-109
12-04	02-219	14-13	14-067	14-16	21-394	16-11	25-503	03-02	41-101	19-21	45-114
11-06	02-251	25-04	14-717	02-06	21-395	02-21	25-517	17-02	41-101	03-20	45-121
11-07	02-263	25-05	14-718	01-28	21-712	16-12	25-517	19-02	41-101	17-21	45-129
11-08	02-266	24-04	14-7210-A	02-07	21-781	16-13	26-553	03-03	41-105	03-21	45-131
11-11	02-301	24-06	15-321	02-08	21-782	02-22	26-712	17-03	41-105	17-22	45-139
12-05	02-408	23-04	15-704	02-09	21-783	01-14	27-017	19-03	41-105	03-22	45-142
11-09	02-488	25-06	15-710	16-03	21-783	01-15	27-018	03-04	41-107	19-22	45-172
11-10	02-489	25-07	15-718	02-10	21-784	22-10	28-011	17-04	41-107	23-12	45-255
13-15	05-954	23-05	17-4430-A	02-11	21-785	22-14	28-311	19-04	41-107	03-23	45-429
14-01	07-295	24-08	17-4430-A	01-29	21-800	22-15	28-312	03-05	41-110	17-23	45-429
14-02	07-388	23-06	17-4430-C	16-04	21-837	22-16	28-313	17-05	41-110	19-23	45-429
14-03	07-389	24-09	17-4430-C	16-05	21-838	22-17	28-314	19-05	41-110	17-24	45-439
14-43	07-3950-2	25-08	17-7150-A	16-06	21-839	22-13	28-317	03-06	41-113	19-24	45-439
14-04	07-3950-A	25-23	17-7180-1	16-07	21-840	22-08	28-452	17-06	41-113	17-25	45-440
14-06	07-3950-B	25-09	17-7180-B	02-12	21-897	22-07	28-464	19-06	41-113	19-25	45-440
14-07	07-3950-C	25-10	17-7180-C	01-05	21-934	22-02	28-611	17-07	41-118	03-24	45-441
14-05	07-3950-D	25-22	17-7190-1	01-06	21-935	22-11	28-614	19-07	41-118	03-25	45-442
15-01	07-701	25-11	17-7190-B	01-07	21-972	22-12	28-615	17-08	41-119	23-24	45-549
15-02	07-702	24-11	17-7210-B	10-02	23-120	22-04	28-920	19-08	41-119	24-21	45-549
15-03	07-703	23-07	17-7600-1	02-13	23-137	10-09	30-0120	03-07	41-120	03-26	47-131
15-04	07-705	10-01	17-8010-G	01-08	23-157	10-31	30-0121	03-08	41-121	03-27	47-132
15-05	07-706	24-12	17-8190-A	10-03	23-160	10-10	31-151	17-09	41-121	17-26	47-171
15-06	07-707	24-13	17-8190-B	05-04	23-195	10-11	31-152	19-09	41-121	19-26	47-172
15-07	07-721	24-14	17-8190-D	06-01	23-197	10-12	31-153	03-09	41-132	08-07	49-139
14-08	07-722	24-15	17-8190-E	01-09	23-206	10-13	31-154	17-10	41-132	06-05	51-017
14-09	07-726	24-16	17-8190-F	02-14	23-229	06-04	31-155	03-10	41-312	06-06	51-031
14-10	07-728	24-17	17-8190-G	01-10	23-263	10-14	31-156	03-11	41-510	07-02	55-041
15-08	07-733	24-29	17-8190-J	01-11	23-285	10-15	31-157	17-11	41-510	07-03	55-051
15-09	07-739	23-09	18-702	02-15	23-296	21-03	31-163	19-10	41-510	14-44	55-053
15-10	07-742	24-18	18-702	04-23	23-296	22-03	31-163	03-12	41-701	18-03	55-055
15-11	07-743	23-10	18-705	10-04	23-304	10-16	31-270	17-12	41-701	20-01	55-055
15-12	07-744	08-01	18-722	03-01	23-324	10-54	31-2700-2	19-11	41-701	07-16	55-155

目錄2/ INDES 2

序號 REF.NO.	圖號 PART NO.
07-23	55-156
14-17	55-156
18-04	55-175
20-05	55-175
07-04	55-176
08-47	60-0800
07-34	60-0900
18-23	60-1120
20-36	60-1120
18-24	60-1230
20-37	60-1230
15-45	60-1330
05-32	60-3700
20-40	60-3720
06-36	60-3760
15-46	60-3830
08-50	60-3910
08-49	60-3920
18-26	60-7200
20-39	60-7200
12-06	61-208
15-19	61-255
08-08	61-312
18-05	61-313
20-06	61-313
07-05	61-322
18-06	61-325
20-07	61-325
08-09	61-513
06-07	61-528
05-07	61-711
12-07	61-714
06-08	61-723
12-08	61-810
20-08	61-823
15-20	61-841
12-09	63-208
15-21	63-211
07-06	63-232
08-10	63-232
18-07	63-232
20-09	63-232
18-08	63-352
20-10	63-352
07-07	63-353
07-35	63-3530-2
06-09	63-515
06-10	63-621
18-09	63-621
20-11	63-621
12-10	63-711
05-08	63-713
12-11	63-810
08-11	63-811
15-22	63-811
08-12	63-812
20-12	63-812
05-09	65-302

序號 REF.NO.	圖號 PART NO.
12-12	65-302
13-17	65-333
08-13	65-435
05-10	66-111
13-18	66-131
08-14	67-132
12-13	67-171
12-14	67-172
13-19	67-180
08-15	67-229
07-08	67-311
18-10	67-312
20-13	67-312
05-11	69-105
05-34	69-1050-2
05-12	69-120
06-11	69-141
06-12	69-216
06-13	69-305
18-25	70-0190
20-38	70-0190
06-38	70-0270
06-37	70-0370
03-28	71-191
17-27	71-191
19-27	71-191
13-20	71-227
04-01	71-255
04-02	71-256
13-21	71-350
13-22	71-361
13-23	71-362
07-09	71-431
08-16	71-431
18-11	71-431
20-14	71-431
05-13	71-432
07-10	71-432
13-24	71-432
11-12	71-443
12-15	71-450
07-11	71-531
09-02	71-542
08-17	71-561
06-14	71-612
07-12	71-642
11-13	71-651
12-16	71-691
12-17	71-726
18-12	71-774
20-15	71-774
06-15	71-794
06-16	71-795
14-19	71-795
18-13	71-878
20-16	71-878
06-17	71-894
14-20	71-894

序號 REF.NO.	圖號 PART NO.
06-18	71-895
14-42	71-895
08-18	71-901
20-17	71-901
11-14	71-921
05-14	71-933
05-15	73-113
05-16	73-115
06-19	75-107
12-18	75-112
08-19	75-114
07-13	75-139
08-20	75-139
14-21	75-152
09-03	75-180
10-30	75-185
12-19	75-211
01-19	75-224
07-14	75-235
18-14	75-235
20-18	75-235
12-20	75-247
15-24	75-254
06-20	75-327
06-21	75-329
05-33	75-332
06-22	75-332
12-21	75-332
08-21	75-372
11-15	75-372
07-15	75-381
14-22	75-381
08-22	75-401
15-25	75-401
04-03	75-436
24-32	75-441
13-25	75-446
11-16	75-451
13-26	75-451
06-23	75-452
08-23	75-452
10-32	75-452
20-19	75-452
20-20	75-453
01-20	75-455
02-24	75-455
03-29	75-455
17-28	75-455
19-28	75-455
23-20	75-455
03-30	75-456
14-18	75-456
17-29	75-456
19-29	75-456
23-25	75-456
24-25	75-456
12-22	75-458
15-26	75-458

序號 REF.NO.	圖號 PART NO.
03-31	75-468
13-27	75-468
15-27	75-468
13-28	75-480
12-23	75-491
12-24	75-493
12-25	75-515
11-17	75-519
14-23	75-519
12-26	75-520
08-24	75-527
02-25	75-528
16-15	75-528
10-19	75-536
08-25	75-552
12-27	75-552
13-29	75-552
06-24	75-673
05-17	75-674
07-17	75-675
08-26	75-675
09-05	77-107
09-06	77-109
09-07	77-116
09-08	77-131
09-09	77-163
09-10	77-164
09-11	77-165
12-28	77-419
12-29	77-420
12-30	77-425
09-04	77-509
09-12	77-516
09-13	77-517
09-14	77-816
09-29	77-818
09-15	79-121
14-24	79-142
15-28	79-148
13-30	79-171
25-16	79-191
12-31	79-425
09-16	79-550
11-18	79-551
24-34	79-571
02-26	79-801
14-25	79-801
16-16	79-801
02-27	79-802
16-17	79-803
02-28	79-922
16-18	79-922
21-04	80-751
22-06	80-751
04-04	81-109
05-18	81-113
13-31	81-125
04-05	81-133

序號 REF.NO.	圖號 PART NO.
04-06	81-153
04-07	81-181
04-08	81-183
04-09	81-184
04-10	81-202
04-11	81-203
04-12	81-236
04-13	81-237
04-14	81-256
11-19	81-321
11-20	81-322
11-21	81-323
08-27	81-401
20-21	81-401
05-19	81-412
15-29	81-704
04-15	81-716
04-16	81-717
04-17	81-718
04-18	81-720
04-19	81-735
04-20	81-753
23-13	84-113
24-23	84-113
25-17	84-113
02-29	84-117
16-19	84-117
03-32	84-161
14-26	84-161
15-30	84-161
17-30	84-161
19-30	84-161
23-14	84-161
11-22	84-162
13-32	84-162
17-31	84-162
19-31	84-162
02-30	84-163
14-27	84-163
24-24	84-163
03-33	84-171
07-18	84-176
07-19	84-177
15-37	84-192
25-18	84-311
13-33	84-314
02-31	84-361
03-34	84-361
16-20	84-361
17-32	84-361
19-32	84-361
08-28	84-362
15-31	84-362
10-43	84-363
14-28	84-363
14-29	84-364
05-20	84-365
05-21	84-366

序號 REF.NO.	圖號 PART NO.
07-20	84-366
08-29	84-366
18-15	84-366
20-22	84-366
10-34	84-367
25-19	84-367
23-23	84-368
25-20	84-368
03-35	84-374
08-30	84-374
17-33	84-374
19-33	84-374
20-23	84-374
23-18	84-382
06-25	84-383
11-23	84-463
07-21	84-464
14-30	84-464
23-19	84-464
24-28	84-464
08-31	84-511
08-32	84-521
15-32	84-521
20-24	84-521
09-17	84-561
09-18	84-562
09-19	84-563
05-22	84-564
14-31	84-566
05-23	84-567
12-32	84-567
06-26	84-568
18-16	84-568
20-25	84-568
14-32	84-571
15-34	84-571
11-24	84-573
02-32	84-574
15-35	84-574
16-21	84-574
25-21	84-575
09-20	84-581
12-33	84-581
12-34	84-582
07-22	84-588
06-27	84-635
08-33	84-635
12-35	84-635
15-33	84-635
20-26	84-635
06-28	84-661
02-33	84-706
16-22	84-706
08-34	84-711
08-35	84-718
15-36	84-727
02-34	84-761
14-33	84-761

目錄3/ INDES 3

序號 REF.NO.	圖號 PART NO.	序號 REF.NO.	圖號 PART NO.	序號 REF.NO.	圖號 PART NO.	序號 REF.NO.	圖號 PART NO.
16-23	84-761	23-16	87-104	09-26	87-252	20-33	91-406
02-35	84-762	24-22	87-104	10-36	87-252	15-44	91-411
16-24	84-762	24-30	87-107	14-38	87-252	13-49	93-200
02-36	84-763	09-24	87-112	18-18	87-252	12-54	93-203
14-34	84-763	02-41	87-113	20-30	87-252	12-55	93-205
03-36	84-764	05-28	87-113	23-17	87-252	11-32	93-221
17-34	84-764	07-26	87-113	24-26	87-252	12-56	93-222
08-36	84-767	11-26	87-113	13-42	87-253	12-57	93-258
15-38	84-812	15-40	87-113	07-29	87-254	07-32	93-261
09-25	84-813	17-37	87-113	08-44	87-254	06-35	93-264
13-34	84-813	19-36	87-113	10-44	87-254	07-33	93-406
02-37	84-862	24-27	87-113	12-47	87-254	08-46	93-406
14-35	84-862	01-24	87-123	13-43	87-254	18-22	93-406
16-25	84-862	02-42	87-123	18-19	87-254	20-34	93-406
02-38	85-181	10-39	87-123	20-31	87-254	09-28	93-611
05-25	85-181	01-25	87-129	02-43	87-261	02-48	93-701
16-26	85-182	10-40	87-129	01-27	87-264	14-40	93-720
09-22	85-201	11-27	87-129	02-44	87-266	14-41	93-727
06-29	85-212	13-38	87-129	16-28	87-266	04-22	94-214
24-35	85-611	10-41	87-140	03-41	87-272	04-24	94-231
23-15	85-618	12-41	87-171	17-40	87-272		
24-36	85-618	05-29	87-172	19-39	87-272		
12-36	85-671	06-32	87-172	06-33	87-274		
02-39	86-266	12-42	87-172	02-45	87-285		
16-27	86-266	08-40	87-173	12-48	87-285		
03-37	86-411	10-37	87-173	16-29	87-285		
08-37	86-411	12-43	87-173	02-46	87-286		
09-30	86-411	01-26	87-177	16-30	87-286		
12-37	86-411	03-39	87-177	10-35	87-287		
15-39	86-411	06-31	87-177	12-49	87-287		
17-35	86-411	09-31	87-177	12-50	87-291		
19-34	86-411	13-39	87-177	02-47	87-292		
08-38	86-412	15-41	87-177	14-39	87-292		
20-27	86-413	17-38	87-177	03-40	87-293		
07-24	86-501	19-37	87-177	17-39	87-293		
08-39	86-501	07-27	87-181	19-38	87-293		
12-38	86-501	08-41	87-181	01-30	87-299		
14-36	86-501	11-28	87-181	10-45	87-311		
20-28	86-501	13-40	87-181	13-44	87-456		
13-35	86-701	14-37	87-181	04-21	87-661		
05-26	86-741	15-42	87-181	12-51	87-754		
12-39	86-741	18-17	87-181	09-27	88-003		
05-27	86-742	20-29	87-181	10-46	88-137		
12-40	86-742	10-42	87-183	12-52	88-146		
09-23	87-004	13-41	87-203	12-53	88-157		
13-36	87-006	08-42	87-213	13-45	88-161		
01-21	87-010	11-25	87-214	13-46	88-166		
10-33	87-010	12-44	87-214	15-43	88-166		
06-30	87-017	05-30	87-225	11-30	88-179		
24-31	87-083	11-29	87-225	13-47	88-456		
01-22	87-092	12-45	87-225	07-30	91-270		
01-37	87-092	05-31	87-242	18-20	91-270		
02-40	87-096	06-34	87-242	20-32	91-270		
23-26	87-096	12-46	87-242	11-31	91-405		
03-38	87-097	07-25	87-245	13-48	91-405		
17-36	87-097	08-43	87-245	07-31	91-406		
19-35	87-097	07-28	87-252	08-45	91-406		
01-23	87-099	08-51	87-252	18-21	91-406		