



细缝系列>720>1、机壳部件（1）


序号	品号	零件名称	数量	备注
1	BF7870101	上盖	1	
2	BF7870102	螺丝（M4-0.7x12）	11	
3	BF7870103	上油镜油封	1	
4	BF7870104	上油镜	1	
5	BF7870105	上盖垫片	1	
6	BF7870106	铭牌	2	
7	BF7870107	上侧盖胶塞	1	
8	BF7870108	上侧盖垫片	1	
9	BF7870109	上侧盖	1	
10	BF7870110	公司铭牌	2	
11	BF7870111	铆钉	4	
12	BF7870112	底线分线盘传动轴护盖	1	
13	BF7200113	圆筒上侧盖	1	
14	BF7200114	侧盖锁门磁铁	1	
15	BF7200115	圆筒部机壳	1	
16	BF7872914	(M5-0.8×16) 螺丝	5	
17	BF7200117	止油垫	1	
18	BF7870118	侧盖枢纽插销	2	
19	BF7200119	圆筒侧盖枢纽	1	
20	BF7200120	螺丝（M4-0.7x12）	2	
21	BF7200121	机壳本体	1	
22	BF7870122	螺丝（M8-1.25x20）	4	
23	BF7870229	螺丝（M4-0.7x4）	1	
24	BF7200124	螺丝（M3-0.5x6）	1	
25	BF7870125	螺丝（M4-0.7x8）	4	
26	BF7870126	磁铁固定压板	1	
27	BF7870127	磁铁	1	
28	BF7870128	机体支柱	4	
29	BF7870129	油槽止油胶垫	1	
30	BF7870130	螺丝（SM3/8"x24*11.5）	1	
31	BF7870131	排油螺丝油封	1	
32	BF7870132	油槽	1	
34	BF7200134	羊毛毡	1	
35	BF7870537	勾线过线孔	1	
36	BF7200136	固定插销（Φ5x8）	2	
37	BF7200137	止油塞（铝）（Φ4.1x6）	1	
38	BF7200138	止油塞（白）（Φ3.2x5）（Φ2.8x2）	2	
39	BF7870503	螺丝	1	
40	BF7870648	螺丝	2	
41	BF7870133	警告贴纸（三角形）	1	
42	BF7870139	警告贴纸（椭圆形）	1	
43	BF7870117	上盖组件	1	
44	BF7870135	上侧盖组件	1	
46	BF7200146	圆筒上侧盖组件	1	
47	BF7200147	止油塞（铝）（Φ3.4x5）	1	
48	BF7200148	止油塞（白）（Φ4.1x7）	1	
49	BF7870144	上油镜组件	1	
JX1	JX7100101	油槽组件	1	



序号	品号	零件名称	数量	备注
1	BF7200201	缝制平台	1	
2	BF7870202	螺丝 (M4-0.7x10)	2	
3	BF7870203	螺丝 (M4-0.7x7)	6	
4	BF7200204	曲轴室上盖	1	
5	BF7200205	曲轴室垫片	1	
6	BF7870107	止油胶塞	4	
7	BF7870125	螺丝 (M4-0.7x8)	3	
8	BF7870208	后盖	1	
9	BF7870209	后盖垫片	1	
10	BF7200210	螺丝 (M3-0.5×10)	1	
12	BF7870212	曲轴室前盖 (小)	1	
13	BF7870213	垫片	2	
14	BF7871712	螺丝 (M3-0.5×4)	1	
15	BF7200215	针板座	1	
16	BF7870216	顶出销	2	
17	BF7870102	螺丝 (M4-0.7x10)	10	
18	BF7870218	螺丝 (M3-0.5x6.5)	2	
19	BF7870219	定位衬套	2	
20	BF7870220	顶出销	1	
24	BF7200224	前盖底座	1	
25	BF7870225	螺丝 (M4-0.7x8)	2	
26	BF7870226	锥形弹簧垫圈	4	
27	BF7870227	螺丝 (M4-0.7x6)	1	
28	BF7801449	前盖铰链	1	
29	BF7870229	螺丝 (M4-0.7x4)	1	
30	BF7870230	螺丝 (M4-0.7x22)	2	
31	BF7200231	前盖顶座	1	
32	BF7870232	螺丝 (M3-0.5x6)	1	
33	BF7870114	锁门弹簧	1	
34	BF7870111	铆钉	1	
35	BF7870235	螺丝 (M4-0.7x8)	2	
36	BF7870236	螺丝 (M4-0.7x4.5)	1	
37	BF7870237	锁门弹簧	1	
39	BF7800239	侧盖锁门磁铁吸片	1	
40	BF7800240	底线分线盘凸轮盖组	1	
41	BF7800241	警告贴纸 (四边形)	1	
42	BF7870238	底线分线盘驱动室盖	1	
44	BF7870244	螺帽	1	
45	BF7870245	螺丝 (M4-0.7x8)	1	
46	BF7870246	螺丝 (M3-0.5x5)	2	
47	BF7870247	底线分线盘凸轮盖	1	
48	BF7870133	警告贴纸 (三角形)	1	
49	BF7870241	警告标贴	1	
50	BF7870249	螺丝 (I级牙) (M4-0.7x3.5)	1	
51	BF7200251	螺丝 (M3-0.5x10)	1	
52	BF7200252	针板支架	1	
53	BF7870257	下切刀托架导引片	1	
54	BF7870258	螺丝 (M4-0.7x4)	1	
55	BF7871622	底线过线护槽	1	
56	BF7870260	螺丝 (M3-0.5x3.3)	1	
57	BF7200257	前盖底座组	1	
58	BF7870259	底线穿线孔	1	
59	BF7200259	针板支架组	1	
60	BF7871009	螺丝 (M3-0.5x3)	2	
61	BF7870291	螺丝 (M4-0.7x6)	1	
62	BF7200262	型号铭牌	1	




序号	品号	零件名称	数量	备注
1	BF7870301	上线张力弹簧调整钮（蓝）	3	
2	BF7870302	张力弹簧调整圆盘	5	
3	BF7870303	针线张力弹簧	3	
4	BF7870304	上饰线张力弹簧	1	
5	BF7870305	下勾针张力弹簧	1	
6	BF7870306	上线张力弹簧固定座	5	
7	BF7870307	毡垫	5	
8	BF7870308	张力调整盘	10	
9	BF7870309	上线张力弹簧支柱	5	
10	BF7870310	上线张力弹簧支柱套圈	5	
11	BF7870311	上线张力圆盘分离器	1	
12	BF7870312	上线张力组支柱座	1	
13	BF7870313	过线导管固定座	1	
14	BF7870229	螺丝（M4-0.7x4）	2	
15	BF7870125	螺丝（M4-0.7x8）	7	
16	BF7870316	上饰线过线杆（左）	1	
17	BF7870317	陶瓷过线孔	15	
18	BF7870318	螺丝（SM1/8"x44-5）	2	
19	BF7870319	螺丝（SM1/8"x44-3）	3	
20	BF7870320	过线导管（长）	1	
21	BF7870321	过线导管（短）	1	
22	BF7870322	上饰线过线杆（右）	1	
23	BF7870323	垫片	4	
24	BF7870324	砂油槽盖	1	
25	BF7870325	砂油储存槽	1	
26	BF7870326	吸油毡	1	
27	BF7870327	针线过线架	1	
28	BF7870328	砂油槽盖固定插销	2	
29	BF7870329	过线杆固定座	1	
30	BF7870330	过线杆	3	
31	BF7870331	针线砂油组	1	
32	BF7870102	螺丝（M4-0.7x12）	5	
33	BF7870333	螺丝（SM9/64"x40-7）	2	
34	BF7870334	砂油储存槽组件	1	
35	BF7870335	上饰组板组件	1	
36	BF7870336	上线张力支柱座组件	1	
37	BF7870337	固定插销	2	
38	BF7870338	固定插销	1	
39	BF7870339	针线导架	1	
40	BF7870340	针线提线杆护架	1	
41	BF7870341	螺丝（M6-1x10）	1	
42	BF7870342	针线张力调整组固定座（小）	1	
43	BF7870343	上线张力弹簧调整钮（红）	2	
44	BF7870344	上线张力支柱座	1	
47	BF7870347	上饰线导板	1	
48	BF7870348	上饰线辅助导板	1	
49	BF7870349	上饰线张力调整组支柱	1	
50	BF7870350	上饰线张力调整盘	2	
51	BF7870351	上饰线张力调整弹簧	1	
52	BF7870352	松紧调钮	1	
53	BF7870353	过线导片	1	
63	BF7870363	过线陶瓷（深灰）	4	



绷缝系列>720>4、套管机构


序号	品号	零件名称	数量	备注
1	BF7870401A	针柱套管（上）	1	
2	BF7870402	针柱套管（下）	1	
3	BF7870403	压脚套管	1	
4	BF7870404	油封	2	
5	BF7870405	上饰线打线器套管	1	
6	BF7870406	油封	1	
7	BF7870407	上饰线打线器传动轴套管（左）	1	
8	BF7870408	上饰线打线器传动轴套管（右）	1	
9	BF7870409	抬压脚连杆套管	1	
10	BF7870410	针线提线杆套管（前）	1	
11	BF7870411	针线提线杆套管（后）	1	
12	BF7200412	送料具提升衬套（后/右）	4	
13	BF7200413	送料具提升衬套（后/左）	3	
14	BF7200414	差动送料具传动轴套管（左）	1	
15	BF7200415	差动送料具传动轴套管（右）	1	
16	BF7200416	主送料具摇臂衬套（左）	1	
17	BF7200417	主送料具驱动轴心衬套	1	
18	BF7870418	油封	1	
19	BF7870419	下勾针传动轴套管（前）	1	
20	BF7870420	下勾针传动轴套管（后）	1	
21	BF7870421	止油封塞	1	
22	BF7870422	护目镜组	1	
23	BF7870423	护目镜固定座	1	
25	BF7870425	护目镜片	1	
26	BF7870426	螺丝（3/32-56×4）	2	
27	BF7870427	护目镜支架	1	
28	BF7870428	螺丝（11/64-40×9.7）	1	
29	BF7870429	锥形弹簧垫圈	1	
30	BF7870430	垫片	1	
31	BF7870431	螺帽	1	
32	BF7870432	油封	1	
33	BF7200433	下传动轴衬套	1	
34	BF7200434	差动送料具驱动轴心套管	1	
35	BF7200435	差动量控制主轴衬套	1	
36	BF7200436	针距控制主轴衬套	1	



细缝系列>720>5、下主轴机构组


序号	品号	零件名称	数量	备注
1	BF7870501	皮带轮	1	
4	BF7870504	滚珠培林（右）	1	
5	BF7870505	扣环	1	
6	BF7870506	底线分线盘驱动链连	1	
7	BF7870507	扣环	1	
8	BF7870508	滚珠培林（中）	1	
9	BF7870509	下传动轴（右）	1	
10	BF7870510	油泵传动连杆	1	
11	BF7870511	平衡配重凸轮	1	
12	BF7870125	螺丝（M4-0.7x8）	2	
13	BF7870513	滚珠培林（左）	1	
14	BF7870514	下曲轴	1	
15	BF7870214	螺丝（M6-1x4）	2	
16	BF7870516	底线导板	2	
17	BF7870559	垫片	1	
18	BF7870545	皮带轮培林组件	1	
19	BF7870519	螺丝（M3-0.5x2.8）	1	
20	BF7870520	锁弹簧	1	
21	BF7870521	底线导板锁压板	1	
22	BF7870202	螺丝（M4-0.7x10）	1	
23	BF7870523	弹簧	1	
24	BF7870524	弹簧衬套	1	
25	BF7870525	底线过线台	1	
26	BF7870526	衬套	1	
27	BF7870527A	底线过线组支架	1	
28	BF7870528	插销	1	
29	BF7870529	底线辅助导板	1	
30	BF7870530	底线张力调整组支柱	1	
31	BF7870350	底线张力调整盘	2	
32	BF7870532	底线过线片（左）	1	
33	BF7870533	底线过线片（右）	1	
34	BF7870534	螺丝（SM9/64"x40-4）	4	
35	BF7870535	底线张力调整弹簧	1	
36	BF7870352	松紧调扭	1	
37	BF7870537	过线片	1	
38	BF7870538	底线过线台总成	1	
39	BF7870539	O型橡胶环	2	
40	BF7870323	垫片	2	
41	BF7870102	螺丝（M4-0.7x12）	2	
42	BF7870542	螺丝（尖底）（M6-1x6）	4	
43	BF7870543	螺丝（M6-1x6）	5	
44	BF7870544	下主轴承轮	1	
45	BF7870562	插销	1	
46	BF7870213	垫片	2	
47	BF7870560	毛根	1	
53	BF7870553	螺丝（M5-1x10）	1	
54	BF787DJZK	电机罩壳	1	
55	BF7870555	螺丝（M5-1x20）	3	
56	BF7870556	直驱式微型伺服马达组	1	
59	BF7870548	油泵传动螺杆组件	1	
62	BF7870565	底线过线台	1	
65	BF7870566A	底线过线组支架	1	
72	BF7870664	O环	2	
73	BF787DJHZ	电机后罩	1	
79	BF787DJZ	电机座	1	
80	BF7870580	螺丝（M5-1x14）	4	
81	BF787ZZ	转子	1	
82	BF7870582	螺丝（M4-1x10）	2	
83	BF787DZ	定子	1	
90	BF7870590	螺丝（M4-1x10）	3	
91	BF787FY	风叶	1	
92	BF787BMQZJ	编码器组件	1	
93	BF7870593	弹性垫片	3	
94	BF7870594	垫片	4	
95	BF7870595	电控	1	

5




细缝系列>720>6、上主轴及针线提线诸元

序号	品号	零件名称	数量	备注
1	BF7870601	手推轮组	1	
2	BF7870602	手推轮	1	
3	BF7870543	螺丝（M6-1x6）	12	
4	BF7870604	手推轮商标铭牌	1	
5	BF7870504	滚珠培林	1	
6	BF7870505	扣环	1	
7	BF7870607	同步传动皮带	1	
8	BF7870608	上主轴链轮	1	
9	BF7870609	上主传动轴（右）	1	
10	BF7870507	扣环	1	
11	BF7870508	滚珠培林	1	
12	BF7870612	上主轴接头	1	
13	BF7870125	螺丝（M4-0.7x8）	2	
14	BF7870511	平衡配重凸轮	1	
15	BF7870615	上曲轴	1	
18	BF7870618	扣环	1	
19	BF7870619	滚珠培林	2	
21	BF7870621	连杆	1	
22	BF7870622	螺丝（M4-0.7x14）	2	
23	BF7870623	螺丝（M4-0.7x12）	2	
24	BF7870624	螺丝（SM1/8"x44-7.3）	2	
25	BF7870625	叉形导片	1	
26	BF7870626	传动杆	1	
27	BF7870627	螺丝（M6-1x15）	1	
28	BF7870628	螺丝（M5-0.8x10）	1	
29	BF7870629	垫片	1	
30	BF7870630	衬套	1	
31	BF7870631	传动轴	1	
32	BF7870632	托架	1	
33	BF7870633	弹性垫片	2	
34	BF7870634	螺丝（M5-0.8x14）	1	
35	BF7870635	针线提线过线杆（三针五线用）	1	
36	BF7870636	上饰板提线过线杆	1	
37	BF7870637	螺丝（M3.5-0.6x8）	2	
38	BF7870503	螺丝（M6-1x8）	2	
39	BF7870639	时规皮带	1	
40	BF7870556	螺丝（M5-0.8x4）	2	
41	BF7870641	滚珠轴承（6201轴承）	2	
42	BF7870642	接头	1	
43	BF7870643	扣环	1	
44	BF7870644	分线盘主传动轴链轮	1	
45	BF7870645	分线盘传动轴	1	
46	BF7870646	底线挑线凸轮	1	
47	BF7870647	轴套	1	
48	BF7870648	螺丝（M5-0.8x5）	2	
49	BF7870649	螺丝（SM7/32"x32-4.5）	2	
50	BF7870650	垫片	4	
51	BF7870651	扣环	2	
52	BF7870652	手推轮转轴套培林组	1	
53	BF7870653	底线挑线凸轮组	1	
54	BF7870654	上主轴接头培林组	1	
55	BF7870655	接头组	1	
56	BF7870656	上曲轴配重组	1	
57	BF7870657	平衡配重凸轮组	1	
58	BF7870658	上曲轴组	1	
60	BF7870659	上饰线提线组	1	
61	BF7870660	传动轴组	1	
62	BF7870661	托架组	1	
64	BF7870664	O环	1	




绷缝系列>720>7、针柱机构

序号	品号	零件名称	数量	备注
1	BF7870701A	针杆	1	
2	BF7870702	螺丝（SM9/64"x40-8）	1	
3	BF7870703	针柱顶过线杆（三针五线用）	1	
5	BF7870705	针杆托架	1	
6	BF7870706	螺丝（M4-0.7x10）	1	
7	BF7870707	针舌	1	
8	BF7870708	机针	3	
9	BF7870319	螺丝（1/8-44x2.6）	4	
10	BF7870710	绷针过线片	1	
11	BF7200711	针板	1	
12	BF7870712	螺丝（M3-0.5x5）	2	
14	BF7870714	平衡配重凸轮	1	
15	BF7870628	螺丝（M5-0.8x10）	1	
16	BF7870716	连杆套环	1	
17	BF7870717	连杆组	1	
18	BF7870718	连杆	1	
19	BF7870719	轴承	1	
20	BF7870720	连杆插销	1	
21	BF7870745	针杆定位组件	1	
22	BF7870722	针杆定位滑块	1	
23	BF7870723	针杆定位导架	1	
24	BF7870724	螺丝（M4-0.7x18）	2	
25	BF7870748	平衡配重凸轮组件	1	
27	BF7870744	上饰过线针舌组	1	
28	BF7870750	垫片	2	
35	BF7870735	螺丝（M2.6-0.45x15）	1	
36	BF7870736	针线过线铁线	1	
37	BF7870737	针线张力调整组固定座（小）	1	
38	BF7870738	针线张力调整压板（小）	1	
39	BF7870739	针线张力调整弹簧	1	
40	BF7870740	螺丝（1/8-44x2.5）	1	
46	BF7870746	螺丝（M8-1.25x16）	2	
47	BF7870747	平衡配重凸轮组	1	
52	BF7870752	螺丝（M10-1.5x4.2）	1	




序号	品号	零件名称	数量	备注
1	BF7870801	调节螺杆	1	
2	BF7870650	垫片	1	
3	BF7870803	调节螺母	1	
4	BF7870804	压杆弹簧（外）	1	
5	BF7870805	压脚杆连接架	1	
6	BF7870806	螺丝（11/64-40x10.5）	1	
7	BF7870807	压脚杆导架	1	
8	BF7870622	螺丝（M4-0.7x14）	2	
9	BF7870809	压杆弹簧（内）	1	
10	BF7870810	压脚杆	1	
11	BF7870811	止油垫	1	
12	BF7870812	挡圈	1	
14	BF7870814	压脚组	1	
15	BF7870815	螺丝（9/64-40x8）	1	
16	BF7870816	压脚弹簧（左）	1	
17	BF7870817	螺丝（1/8-44x3）	1	
18	BF7870818	垫片	1	
19	BF7870819	螺丝（3/32-56x4）	4	
20	BF7870820	压脚插销	1	
21	BF7870821	螺丝（1/8-44x4）	1	
22	BF7870822	螺母	1	
23	BF7870823	可调螺丝	1	
24	BF7870824	压脚弹簧（右）	1	
25	BF7870825	螺丝（3/32-56x3）	1	
26	BF7870826	压脚舌	1	
27	BF7870827	提升连杆	1	
28	BF7870828	螺丝（3/16-32x3.5）	2	
29	BF7870829	提升连接拉柄	1	
30	BF7870830	固定销	1	
31	BF7870831	弹簧	1	
32	BF7870832	挡圈（8x16x8）	2	
33	BF7870833	螺丝（M4.5-0.75x5.5）	2	
34	BF7870834	压脚提升主轴	1	
35	BF7870835	螺丝（M4-0.7x3）	2	
36	BF7870836	中间拉柄	1	
37	BF7870634	螺丝（M5-0.8x14）	1	
38	BF7870838	卡簧	2	
39	BF7870839	连接销	2	
40	BF7870840	连接拉板	1	
41	BF7870841	提升拉柄（小）	1	
42	BF7870543	螺丝（M6-1x6）	1	
43	BF7870843	提升拉柄	1	
44	BF7870844	提升拉柄挡块	1	
45	BF7870845	螺丝（9/64-40x5.5）	2	
46	BF7870846	拉力释放杆	1	
47	BF7870847	螺丝（11/64-40x14）	1	
48	BF7870848	拉力释放轴	1	
50	BF7870850	割线刀	1	
51	BF7870851	割线刀座	1	
52	BF7870852	压脚弹簧调节器组	1	
53	BF7870853	压脚推杆连接组	1	
55	BF7870855	轴环组	1	
56	BF7870856	压脚弹簧	1	
65	BF7870865	压脚推杆组	1	
67	BF7870867	提升连接拉杆组	1	
68	BF7870868	轴环组	2	
69	BF7870869	连接拉板组	1	
70	BF7870870	提升拉柄组	1	
72	BF7870872	压脚头	1	
73	BF7870873	挡片	1	
75	BF7870875	侧边压板	2	
76	BF7870876	割线刀座组	1	
77	BF7870877	挡片	1	
78	BF7870878	压脚本体	1	
80	BF7870880	螺丝（1/8-44x3）	1	

8



缝绗系列>720>9. 上饰线驱动机构


序号	品号	零件名称	数量	备注
2	BF7870902	偏心轮	1	
3	BF7870503	螺丝 (M6-1x8)	2	
4	BF7870904	轴承	1	
5	BF7870905	连杆	1	
6	BF7870906	卡簧	1	
7	BF7870125	螺丝 (M4-0.7x8)	1	
8	BF7870908	垫片	1	
9	BF7870909	插销	1	
10	BF7870547	垫片	1	
11	BF7870911	螺母 (M6-1.0)	1	
12	BF7870912	挡圈 (12x20x8)	1	
13	BF7870913	螺丝 (M4-0.7x6)	2	
14	BF7870914	可调式拉柄	1	
15	BF7870915	螺丝 (M6-1x16)	1	
16	BF7870916	主动轴	1	
17	BF7870917	摇臂	1	
18	BF7870543	螺丝 (M6-1x6)	2	
19	BF7870919	支点销	1	
20	BF7870920	延展臂	1	
21	BF7870921	衬环	1	
22	BF7870922	轴环 (10x18x7)	1	
23	BF7870229	螺丝 (M4-0.7x4)	2	
24	BF7870924	上勾固定座	1	
25	BF7870925	上勾	1	
26	BF7870102	螺丝 (M4-0.7x12)	2	
29	BF7870929	偏心轮连杆培林组	1	
30	BF7870930	偏心轮组	1	
31	BF7870931	轴环组	1	
33	BF7870933	摇臂组	1	
34	BF7870934	轴环组	1	
36	BF7870936	主动轴组	1	
37	BF7870937	延展臂组	1	




细缝系列>720>10、下勾针驱动机构

序号	品号	零件名称	数量	备注
1	BF7871001MF	下弯针	1	
2	BF7871002	螺丝 (M3. 5-0. 6x6)	1	
3	BF7201003	下弯针固定座	1	
4	BF7871004	螺丝 (M3. 5-0. 6x10)	1	
5	BF7871005	垫片	3	
6	BF7201006	下勾针驱动轴衬套	1	
7	BF7870503	螺丝 (M6-1x8)	2	
11	BF7871011	衬套垫片	1	
12	BF7871012	下勾针驱动轴导槽	1	
13	BF7871013	滑块	1	
14	BF7871014	滑块固定座	1	
15	BF7870102	螺丝 (M4-0. 7x12)	2	
16	BF7871016	摇臂夹座	1	
17	BF7871017	滑块定位压块	1	
18	BF7870229	螺丝 (M4-0. 7x4)	1	
19	BF7871019	垫片	2	
20	BF7871020	封闭塞	2	
21	BF7871021	下弯针杆	1	
22	BF7871022	垫片	1	
23	BF7201023	下弯针导轨	1	
24	BF7871024	螺丝 (M5-0. 8x30)	1	
25	BF7871025	垫片	2	
26	BF7871026	下弯针摇臂调整销	1	
27	BF7871027	销	1	
28	BF7871028	螺母	1	
29	BF7871029	弯针摇臂连杆组	1	
30	BF7871030	下弯针摇臂可调偏心轮	1	
31	BF7870648	螺丝 (M5-0. 8x5)	1	
32	BF7871032	滚针轴承	1	
33	BF7871033	下弯针摇臂连杆	1	
34	BF7871034	下弯针连杆	1	
35	BF7871035	螺丝 (M4-0. 7x14)	2	
36	BF7871036	拨油片	1	
37	BF7871037	定位叉	1	
38	BF7871038	螺丝 (11/64-40x8)	2	
39	BF7871039	下弯针驱动杆	1	
40	BF7871040	封塞	1	
41	BF7871041	下弯针摇臂	1	
42	BF7871042	螺丝 (M6-0. 75x15)	1	
43	BF7871043	推力板	1	
44	BF7871044	推力滚珠轴承	1	
45	BF7871045	下弯针主轴	1	
46	BF7871046	封塞	1	
47	BF7870628	螺丝 (M5-0. 8x10)	1	
48	BF7870633	弹簧垫片	1	
49	BF7871049	下勾针杆组	1	
50	BF7870622	螺丝 (M4-0. 7x14)	2	
51	BF7871051	滑块固定座组	1	
53	BF7871053	下勾针摇臂偏心轮组	1	
54	BF7871050	摇臂夹座组	1	
55	BF7871055	下勾针摇臂连杆组	1	
56	BF7871056	下勾针驱动杆组	1	
57	BF7870557	螺丝 (M6-1x10)	2	
58	BF7871058	下勾针摇臂组	1	
59	BF7871059	下勾针主轴组	1	
60	BF7871060	滑块固定座	1	
61	BF7201061	下勾针组	1	


10



序号	品号	零件名称	数量	备注
1	BF7201101	主送料具固定座	1	
2	BF7201102A	主齿	1	
3	BF7201103	主齿键	2	
4	BF7801261	螺丝（M3-0.5x8）	2	
5	BF7201105	差动送料具固定座	1	
6	BF7201106	送料具导轨插销	1	
7	BF7870125	螺丝（M4-0.7x8）	2	
8	BF7201108	送料具导轨	1	
9	BF7201109	主送料具轴驱动连杆	1	
10	BF7201110	驱动连杆衬套	1	
11	BF7870323	垫片	1	
12	BF7871221	螺丝（M4-0.7x24）	1	
13	BF7201113	驱动连杆插销	1	
14	BF7201114	封闭塞（Φ3珠子）	2	
15	BF7870229	螺丝（M4-0.7x4）	5	
16	BF7201116	主送料具摇臂	1	
17	BF7201117	封闭塞（Φ4珠子）	1	
18	BF7201118	主送料具摇臂主轴	1	
19	BF7801169	封闭塞（Φ2.2x2.5）（白）	5	
20	BF7201120	主送料具提升杆销	1	
21	BF7870543	螺丝（M6-1x6）	4	
22	BF7201122	主送料具提升杆	1	
23	BF7201123	主送料具提升主轴	1	
24	BF7201124	主送料具提升连杆	1	
25	BF7201125	提环杆（长）	1	
26	BF7871104	螺丝（M4-0.7x4.5）	2	
27	BF7201127	提环杆（短）	1	
28	BF7201128	连杆销	1	
29	BF7871121	连杆导轨	1	
30	BF7870542	螺丝（M6-1x6）	1	
32	BF7201132	主齿控制架	1	
33	BF7870503	螺丝（M6-1x8）	2	
34	BF7201134	送料具偏心轮	1	
35	BF7871107	滚针轴承	1	
36	BF7871106	卡簧	1	
37	BF7201137	送料连杆	1	
38	BF7201138	连杆销	1	
39	BF7871259	羊毛毡	1	
40	BF7201140	封闭塞（Φ2.5x1.5）（白）	2	
41	BF7201141	封闭塞（Φ4.1x3）（白）	2	
42	BF7201142	轴环	2	
43	BF7201143	轴环组件	2	
45	BF7201145A	差动齿	1	
46	BF7201146	主送料具轴	1	
47	BF7871242A	差动齿（中间小齿）	1	
48	BF7870735	螺丝（M2.6-0.45x5）	1	
49	BF7201149	送料具提升滑轨	2	
50	BF7201150	送料具固定座组成	1	
51	BF7201151	送料具摇臂组	1	
52	BF7201152	送料具导轨组	1	
53	BF7201153	主送料具摇臂主轴组	1	
54	BF7201154	主送料具提升主轴组	1	
55	BF7201155	主送料具提升杆组	1	
56	BF7201156	主送料具提升杆销组	1	
57	BF7201157	送料具偏心轮组	1	
58	BF7201158	送料具连杆销组	1	
59	BF7201159	送料具提升连杆组	1	
60	BF7201160	主送料具摇臂组	1	
61	BF7201161	驱动连杆插销组	1	
62	BF7201162	主齿（薄料用）	1	
63	BF7201163	差动齿（薄料用）	1	
64	BF7871264	差动齿（中间小齿）（薄料用）	1	




序号	品号	零件名称	数量	备注
1	BF7201201	差动送料具驱动杆	1	
2	BF7870543	螺丝（M6-1x6）	4	
3	BF7201203	连杆销	1	
4	BF7201114	封闭塞（Φ3珠子）	4	
5	BF7201205	连杆销	1	
6	BF7201206	差动送料具驱动连杆	1	
7	BF7871104	螺丝（M4-0.7x4.5）	4	
8	BF7201208	差动送料具驱动轴	1	
9	BF7201209	差动送料具连杆	1	
10	BF7801169	封闭塞（Φ2.2x2.5）（白）	4	
11	BF7201211	油封	2	
12	BF7201212	停止轴环	1	
13	BF7201213	连杆销	1	
14	BF7201214	封闭塞（Φ2.5珠子）	1	
15	BF7201215	连杆插销	1	
16	BF7201216	连杆	2	
18	BF7201218	连杆	1	
19	BF7201219	连杆插销	1	
20	BF7201220	螺丝（M5-0.8x6）	1	
21	BF7870648	螺丝（M5-0.8x5）	2	
22	BF7201222	控制架	1	
23	BF7201223	连杆导轴（短）	1	
24	BF7201141	封闭塞（Φ4.1*3）（白）	1	
25	BF7201225	差动送料具驱动曲柄	1	
26	BF7870229	螺丝（M4-0.7x4）	5	
27	BF7201227	差动送料具摇臂	1	
29	BF7201229	差动送料具提升连杆	1	
30	BF7201113	驱动连杆插销	1	
31	BF7201231	连杆衬套	1	
32	BF7870323	垫片	1	
33	BF7870724	螺丝（M4-0.7x18）	1	
39	BF7201140	封闭塞（Φ2.5*1.5）（白）	1	
40	BF7201142	轴环	2	
41	BF7201241	差动送料具驱动杆组	1	
42	BF7201242	连杆销组	1	
43	BF7201243	连杆销组	1	
44	BF7201244	差动送料具驱动连杆组	1	
45	BF7201245	差动送料具摇臂组	1	
46	BF7201246	差动送料具驱动连杆组	1	
47	BF7201247	连杆销组	1	
48	BF7201248	连杆插销组	1	
50	BF7201250	连杆组	1	
51	BF7201251	差动送料具驱动曲轴组	1	
52	BF7201161	驱动连杆插销组	1	
53	BF7201253	差动送料具摇臂组	1	
54	BF7201143	轴环组件	2	
55	BF7201117	封闭塞（Φ4珠子）	1	
56	BF7201256	差动送料具驱动轴组	1	




细缝系列>720>13、顶针片及送料具驱动机构

序号	品号	零件名称	数量	备注
1	BF7201301	送料具驱动主轴	1	
2	BF7201302	垫片	1	
3	BF7201303	滚针培林	1	
4	BF7201304	连杆销	1	
5	BF7201214	封闭塞（Φ2.5珠子）	3	
6	BF7201306	送料具连杆	1	
7	BF7201307	垫片	1	
8	BF7870256	螺丝（M4-0.7x8）	1	
9	BF7201309	送料具驱动轴转接架	1	
10	BF7870648	螺丝（M5-0.8x5）	1	
11	BF7870229	螺丝（M4-0.7x4）	17	
12	BF7201142	轴环	6	
13	BF7201140	封闭塞（Φ2.5*1.5）白	2	
14	BF7201314	主齿驱动曲柄	1	
16	BF7201316	差动齿驱动曲柄	1	
17	BF7201317	差动齿提升拉杆	1	
19	BF7201319	送料具提升拉杆	1	
20	BF7201320	送料具提升连杆插销	2	
21	BF7201321	螺丝（M3-0.5x10）	1	
22	BF7201322	间隔衬套	1	
23	BF7201323	顶针片（前）固定座	1	
27	BF7201327	顶针片（后）	1	
28	BF7201328	顶针片（后）固定座	1	
29	BF7201329	接头套筒	1	
30	BF7201330	顶针片驱动曲轴	1	
31	BF7201331	连杆	1	
32	BF7201332	顶针片偏心轮	1	
34	BF7801169	封闭塞（Φ2.2x2.5）（白）	2	
35	BF7871027	辊子销	1	
36	BF7871914	螺丝（M5-0.8x12）	1	
37	BF7201337	弹簧垫片	1	
38	BF7871259	羊毛毡	2	
39	BF7201141	封闭塞（Φ4.1*3）白	2	
40	BF7201340	送料具提升连杆插销组	2	
41	BF7201341	送料具驱动轴转接架组	1	
42	BF7201143	轴环组件	6	
43	BF7201343	连杆销组	1	
44	BF7201344	送料具驱动主轴组	1	
45	BF7201345	主齿驱动曲轴组	1	
46	BF7201346	差动齿驱动曲轴组	1	
47	BF7201347	顶针片偏心轮组	1	
48	BF7201348	顶针片驱动曲轴组	1	
49	BF7201349	接头套筒组	1	
50	BF7201350	顶针片（后）固定座组	1	
51	BF7201351	顶针片（前）固定座组	1	

13




绷缝系列>720>14、主齿及差动齿调整盘机构

[illegible]


序号	品号	零件名称	数量	备注
1	BF7871301	接油盘	1	
2	BF7870125	螺丝（M4-0.7x8）	8	
3	BF7871303	螺母	1	
4	BF7871304	油线	2	
5	BF7871305	油管	1	
6	BF7870229	螺丝（M4-0.7x4）	3	
9	BF7871309	油线固定座	1	
10	BF7870702	螺丝（9/64-40x7.5）	1	
11	BF7871311	滤油器盖	1	
12	BF7871312	螺丝（11/64-40x16）	3	
13	BF7871313	O型圈	1	
14	BF7871314	滤油器	1	
15	BF7871315	滤油器接管（3/8-28x6）	1	
16	BF7871316	吸油棉	1	
17	BF7871317	回油管	1	
18	BF7871318	回油管衬套	1	
19	BF7871319	油管（3x5x440）	1	
20	BF7871320	油管套	1	
21	BF7871321	喷油管	1	
22	BF7871358	油管组（长）	1	
23	BF7870547	垫片	1	
24	BF7871324	油管（4×6×100mm）	1	
25	BF7871325	油管阀	1	
26	BF7871326	油管（4×6×280mm）	1	
27	BF7871327	油管接头（双向）	1	
28	BF7871328	油管（4×6×35mm）	1	
29	BF7871329	油管接头（单向）	5	
30	BF7201530	筒壁转轴部喷油管	1	
31	BF7871331	油管组（中段）	1	
32	BF7871332	油管（4×6×50mm）	1	
33	BF7871333	筒臂勾针轴部喷油孔	1	
34	BF7871334	油管（4×6×30mm）	1	
36	BF7871336	放油螺丝（短）（1/4-40x16）	4	
37	BF7871337	垫片	3	
38	BF7871338	放油螺丝（长）（1/4-40x27）	1	
39	BF7871339	油管组（短）	1	
40	BF7871340	油泵组	1	
41	BF7871341	油泵蜗杆组	1	
42	BF7871242	吸油棉	1	
43	BF7870915	螺丝（M6-1x16）	2	
44	BF7871344	吸油管	2	
45	BF7871345	螺母	1	
46	BF7871346	驱动轴蜗齿组喷油嘴	1	
47	BF7871347	防尘盖	1	
48	BF7871348	油管固定架	1	
49	BF7871349	外观油量表	1	
50	BF7871356	滤油器盖组	1	
51	BF7201551	油管接头（单向）	1	
52	BF7401139	放油螺丝（3/16-32x13.5）	1	
53	BF7401140	垫片	2	
54	BF7201554	油管转接头	2	
55	BF7871355	垫片	1	
56	BF7201556	油管（3×5×365mm）	3	
57	BF7871357	贴纸	1	
58	BF7871374	润滑油接收盘组	1	
59	BF7871359	回油管组	1	
60	BF7871364	油泵组	1	
61	BF7871361	油管	1	
62	BF7871362	双向油管接头组	1	
63	BF7871354	配线固定组	1	
65	BF7871365	油泵本体	1	
66	BF7871366	油泵转子	2	
67	BF7871367	油泵转子	2	
68	BF7871368	油泵转子	1	
69	BF7871369	油泵转子	1	
70	BF7871370	油泵主轴	1	
71	BF7871371	下座盖	1	
72	BF7871372	螺丝（M4-0.7x40）	4	
77	BF7871377	油泵本体（下座）	1	
78	BF7871378	油泵本体（中座）	1	
79	BF7871379	管束	3	
81	BF7870323	垫片	1	

15



绷缝系列>720>16、自动切线松线机构


序号	品号	零件名称	数量	备注
1	BF7871501	压脚拉杆	1	
2	BF7871502	拉杆止架	1	
3	BF7870845	螺丝 (9/64-40x5.5)	2	
4	BF7871504	连接杆	1	
5	BF7870622	螺丝 (M4-0.7x14)	1	
6	BF7871506	滑块	1	
7	BF7870214	螺丝 (M6-1x4)	1	
8	BF7871508	连接压板	1	
9	BF7870125	螺丝 (M4-0.7x8)	3	
10	BF7870706	螺丝 (M4-0.7x10)	2	
11	BF7871511	螺丝 (M4-0.7x4.5)	1	
12	BF7870363	过线陶瓷 (深灰)	4	
14	BF7871514	挡圈	1	
15	BF7870319	螺丝 (1/8-44x2.6)	7	
16	BF7871516	松线压板组	1	
17	BF7871517	松线轴	1	
18	BF7871518	过线松线架	1	
19	BF7871519	过线松线杆	1	
20	BF7871520	防震弹簧	1	
21	BF7870229	螺丝 (M4-0.7x4)	3	
22	BF7871522	松线钩组 (单脚)	3	
23	BF7871523	松线钩	7	
24	BF7871524	过线松线杆固定座	1	
25	BF7871525	松线钩组 (双脚)	2	
27	BF7871527	压脚拉杆组	1	
28	BF7871528	卡簧	1	
29	BF7871529	松线拉柄	1	
30	BF7871530	松线调整螺丝 (M4-0.7x5.5)	1	
31	BF7871531	弹簧	1	
32	BF7871532A	过线张力组	1	
33	BF7870102	螺丝 (M4-0.7x12)	4	
34	BF7871534	垫圈	4	
35	BF7871535	分离架	1	
36	BF7871536	轴环组	1	
37	BF7871537	松线钩组	3	
38	BF7871538	松线钩组	2	
39	BF7871539	松线拉柄组	1	
40	BF7870301	上线张力弹簧调整钮 (蓝)	3	
41	BF7870343	上线张力弹簧调整钮 (红)	2	
42	BF7870302A	张力弹簧调整圆盘	5	
46	BF7870306	上线张力弹簧固定座	5	
47	BF7870307	毡垫	5	
48	BF7870308	张力调整盘	10	
49	BF7870309A	上线张力弹簧支柱	5	
50	BF7870310	上线张力弹簧支柱套圈	5	
51	BF7870317	陶瓷过线孔	20	
53	BF7870313	过线导管固定座	1	
54	BF7870320	过线导管 (长)	1	
55	BF7870321	过线导管 (短)	1	
56	BF7870312	上线张力组支柱座	1	
57	BF7870835	螺丝 (M4-0.7x3)	7	
58	BF7871104	螺丝 (M4-0.7x4.5)	1	
59	BF7871559	螺丝 (M4-0.7x2.5)	1	
60	BF7871560	弹簧	1	
61	BF7870368	过线导管 (短) 组	1	
62	BF7870369	过线导管 (长) 组	1	
63	BF7871563	过线松线架组	1	
64	BF7870372	针线张力弹簧	3	
65	BF7870373	上饰线张力弹簧	1	
66	BF7870374	下勾针张力弹簧	1	





绷缝系列>720>17、底线切线刀机构

序号	品号	零件名称	数量	备注
1	BF7871601	下刀连杆	1	
2	BF7871602	螺丝 (M4-0.7x8.5)	1	
3	BF7871603	护环	2	
4	BF7871604	垫片	2	
5	BF7870203	螺丝 (M4-0.7x7)	1	
6	BF7871606	下刀托架	1	
7	BF7871607	螺丝 (M3-0.5x2.8)	2	
8	BF7871608	下刀插接头	1	
9	BF7871609	下刀	1	
10	BF7871610	下刀固定座	1	
11	BF7871611	上刀托架	1	
12	BF7871612	螺丝 (M4-0.7x4)	2	
13	BF7871613	螺母	2	
14	BF7871614	摇臂	2	
15	BF7871615	摇臂偏心轮	2	
16	BF7871616	螺丝 (M4-0.7x7)	2	
18	BF7871618	上刀托架板	1	
19	BF7870258	螺丝 (M4-0.7x4)	2	
20	BF7871620	扭簧	1	
21	BF7871621	螺丝 (M4-0.7x2.7)	1	
22	BF7871622	过线槽	1	
23	BF7871009	螺丝 (M3-0.5x3)	2	
24	BF7201724	曲柄轴室盖	1	
25	BF7871625	螺丝 (M2-0.4x4)	2	
26	BF7871626	上刀	1	
27	BF7871627	螺丝 (M2-0.4x5.6)	3	
28	BF7871628	螺丝 (M2-0.4x10)	1	
29	BF7871629	下刀组	1	
30	BF7871630	上刀架	1	
31	BF7871631	弹簧片	1	
32	BF7871632	弹簧刀片	1	
33	BF7871633	固定座	1	
34	BF7871634	调整片	1	
38	BF7201738	缝台 (电切)	1	
39	BF7870202	螺丝 (M4-0.7x10)	2	
40	BF7201740	下刀固定座 (伸缩尼龙绳专用)	1	
41	BF7871641	下刀 (防脱线)	1	
42	BF7871642	下刀组 (防脱线)	1	


17




序号	品号	零件名称	数量	备注
1	BF7871701	拨线电磁铁	1	
2	BF7871702	螺母	2	
3	BF7871703	缓冲弹簧吊架	1	
4	BF7871704	拨线摇臂导块	1	
5	BF7871705	缓冲弹簧	1	
6	BF7871706	电磁铁摇臂插销	1	
7	BF7871707	螺丝（M3-0.5x5）	1	
8	BF7871708	电磁铁摇臂	1	
9	BF7871709	卡簧	1	
10	BF7870256	螺丝（M4-0.7x8）	1	
11	BF7871711	拨线摇臂	1	
12	BF7871712	螺丝（M3-0.5x4）	1	
13	BF7871713	拨线钩固定座	1	
14	BF7871714	拨线钩	1	
15	BF7871715	螺丝（M2-0.4x2）	1	
16	BF7871716	夹线弹簧片	1	
17	BF7871717	拨线电磁铁托架	1	
18	BF7871718	拨线电磁铁组件	1	
19	BF7871719	螺丝（3/32-56x6）	2	
20	BF7871720	上刀压力调整片	1	
21	BF7871721	压力调整隔片	1	
22	BF7871722	上刀固定刀	1	
23	BF7871723	螺丝（3/32-56×8）	1	
24	BF7871724	螺丝（3/32-56×4）	5	
25	BF7871748	上刀电磁铁组	2	
26	BF7871726	夹线压力片	1	
27	BF7871727	夹线压力隔片	1	
28	BF7871728	夹线片	1	
29	BF7871729	上刀导槽托架	1	
30	BF7871730	电磁铁	1	
31	BF7871731	螺母	1	
32	BF7871732	垫片	1	
33	BF7871733	弹簧垫片	1	
34	BF7871734	螺母	1	
35	BF7871735	上活动刀片	1	
36	BF7871736	螺丝（M2-0.4x4）	1	
37	BF7871737	上刀架	1	
38	BF7871738	电磁式上切线组	1	
39	BF7871739	电磁式上拨线	1	
41	BF7871741	配线固定组	1	
42	BF7871742	拨线钩连接组件	1	
44	BF7871744	拨线端子护套	1	
45	BF7871745	端子座	2	
46	BF7871746	垫片	2	
47	BF7871747	螺丝（M4-0.7x12）	1	
48	BF7871748	端子	1	
49	BF7871749	塑料管（黑）	1	
50	BF7871750	电磁式上拨线	1	
51	BF7871751	螺丝（M4-0.7x8）	1	



绷缝系列>720>19、气压式上切线机构

[illegible]


绷缝系列>720>20、电磁式直接驱动抬压脚组

[illegible]


绷缝系列>720>21、气压式抬压脚组

[illegible]

21




绷缝系列>720>22、电磁式下切刀驱动机构


[illegible]

绷缝系列>720>23、气压式下切刀驱动机构

NO	CODE	NAME	数量	备注
1	BF7872201	螺帽	1	
2	BF7872202	气压缸	1	
4	BF7872204	气压电磁阀组	1	
5	BF7872106	胶套	1	
6	BF7872206	避震胶垫	1	
7	BF7872120	调整环	1	
8	BF7870634	螺丝（M5-0.8x14）	1	
9	BF7872209	空压管吊架	1	
10	BF7870628	螺丝（M5-0.8x10）	3	
11	BF7872211	下切刀空压管座	1	
12	BF7870546	螺丝（M6-1x20）	2	
14	BF7872214	安全开关座	1	
15	BF7870125	螺丝（M4-0.7x8）	2	
16	BF7872216	安全开关	1	
17	BF7872217	垫片	1	
18	BF7872218	螺丝（SM11/64-40x5）	1	
19	BF7872219	安全开关导片	1	
20	BF7872220	螺丝（M3-0.5x4.7）	2	
21	BF7872221	螺丝（M4-0.7x25）	4	
22	BF7872222	螺帽	1	
23	BF7872119	柱塞式连杆	1	
24	BF7872224	柱塞接头	1	
25	BF7871914	螺丝（M5-0.8x12）	2	
26	BF7872226	连结滑块	1	
27	BF7872227	连结滑块组	1	
28	BF7872228	空压管复进轴	1	
29	BF7870832	轴环	1	
30	BF7870833	螺丝（M4.5-0.75x5.5）	1	
31	BF7872231	空压管复进簧	1	
32	BF7872232	螺丝（M4-0.7x8）	1	
33	BF7872233	弹簧	1	
34	BF7870547	垫片	1	
35	BF7872235	柱塞止环组	4	
36	BF7870648	螺丝（M5-0.8x5）	1	
37	BF7872237	柱塞止环	2	
39	BF7872111	端子组	1	
40	BF7872240	气压阀整组	1	
41	BF7872113	束带	1	
42	BF7872242	安全开关座组	2	
43	BF7872243	安全开关导片组	1	
44	BF7872244	柱塞接头组	1	
45	BF7872245	轴环组	1	
46	BF7872246	一般风切	1	
48	BF7872248	端子	1	
49	BF7872115	压脚端子	1	
50	BF7872114	上下切端子	1	
52	BF7872252	电磁阀	1	
53	BF7871807	肘型接头	2	
54	BF7872254	电磁阀调速接头	4	
55	BF7872255	电磁阀底座接头	1	
56	BF7871354	配线固定钮	1	
57	BF7870323	垫片	1	
58	BF7872110	螺丝（M3-0.5x12）	1	



绷缝系列>720>24、线架及机头托架组

[illegible]

序号	品号	零件名称	数量	备注
1	BF7873304	底座避震胶垫	4	
2	BF7202630	短底座固定螺丝	2	
3	BF7202641	螺钉(短)	2	
4	BF7202637	长底座固定螺丝	2	
5	BF7202642	螺钉(长)	2	
6	BF7202643	垫片	4	
7	BF7202639	弹簧垫片	4	
8	BF7202635	底座支架橡胶避震垫片	20	
9	BF7202640	螺帽	8	
10	BF7202638	垫片	4	
11	BF7202633	吊架螺栓	4	
12	BF7202634	垫片	8	
13	BF7202636	螺帽	8	
14	BF7202644	弹簧垫片	4	
15	BF7873201	梅花扳手	1	
16	BF7202801	油壶	1	
17	BF7202802	漏斗	1	
18	BF7803529	内六角扳手6mm	1	
19	BF7803506	内六角扳手5mm	1	
20	BF7803505	内六角扳手4mm	1	
21	BF7803504	内六角扳手3mm	1	
22	BF7803503	内六角扳手2.5mm	1	
23	BF7803502	内六角扳手2mm	1	
24	BF7803528	内六角扳手1.5mm	1	
25	BF7873215	穿线铁丝	1	
26	BF7870735	螺钉	2	
27	BF7873228	布导器(左)	1	
28	BF7873229	布导器(右)	1	
29	BF7873216	一字螺丝刀(小)	1	
30	BF7873320	大油壶	1	
31	BF7873220	镊子	1	
32	BF7873217	一字螺丝刀(中)	1	
33	BF7873218	一字螺丝刀(大)	1	
34	BF7871314	滤油器	1	
35	BF7202714	机针组	5	
36	BF7873502	脚踏开关	1	
37	BF7873313	托架	2	
41	BF7202645	拉杆	1	
42	BF7870102	螺钉	2	
43	BF7870924	固定座	1	
44	BF7870925	绷针	1	
45	BF7870347	上饰线导板	1	
46	BF7870350	线张力调整盘	1	
47	BF7870351	弹簧垫片	1	
48	BF7870352	松紧旋钮	1	
49	BF7870348	辅助导板	1	
50	BF7870349	调整支柱	1	
51	BF7870321	过线管(短)	1	
52	BF7870320	过线管(长)	1	
53	BF7870125	螺钉	1	
54	BF7870313	固定座	1	
55	BF7870229	螺钉	2	
56	BF7870312-1	导线架	1	
57	BF7202646	卡扣	5	
58	BF7873101	线架组件	1	

