



小方头绷缝机零件图册



一、机壳部件/MACHINE BED FRAME

序号 NO.	品号	CODE	名称	NAME	数量 Number
1	BF31016206590		油标	OIL LEVEL GAUGE	1
2	BF31016250117		机壳螺钉	BED PIN	4
4	BF31016240052		油封	PLUG	1
5	BF31016240052		油封	PLUG	1
6	BF31016240110		油封	PLUG	1
7	BF32026210003		油封	PLUG	1
8	BF32026209084		油封	PLUG	1
9	BF31016240226		密封盖	PLUG	1
10	BF31016240045		油堵	PLUG	1
11	BF7005M109		油封	PLUG	1
12	BF31016124		滤油网	FILTER	1
13	BF31016240001		滤油网卡簧	RING	1
14	BF31016255108		销	PIN	1
15	BF31016207358		油点	FELT	1
16	BF320267017		螺钉	SCREW	2
17	BF31016250020		盖板	COVER	1
18	BF32026250157		盖板垫	SPONGE	1
19	PF1900A0704		螺钉	SCREW	1
20	BF310164539		螺钉	SCREW	2
21	BF31016210586		垫圈	OIL SEAL	1
22	SC16071		螺钉	PIN	2


二



二、罩壳部件/COVER

序号 NO.	品号	CODE	名称	NAME	数量 Number
1	BFBW0206		上盖	ARM COVER (TOP)	1
2	BF31016240226		密封盖	PLUG	1
3	BF31016179107		油标盖	OIL SIGHT WINDOW	1
4	BFBW0209		上盖垫	O RING	1
5	BF310167021		螺钉	SCREW	7
6	BF0201L		面板	ARM COVER (LEFT)	1
7	BF310165242		螺钉	SCREW	1
8	BF0202		面板垫	O RING	1
9	BF310167022		螺钉	SCREW	4
10	BF31016240263		垫圈	WASHER	1
11	BF32026250154		后盖板	ARM COVER (REAR)	1
12	BF32026250155		后盖板垫	GASKET	1
13	BF310167052		螺钉	SCREW	6
14	BF31016250021		护罩	NEEDLE BAR GUARD	1
15	BF310167019		螺钉	SCREW	2
16	BF32026250234		护线罩	NEEDLE BAR GUARD	1
17	BF310167019		螺钉	SCREW	1
18	BF31016250255		护罩座	BRACKET	1
19	BF310167020		螺钉	SCREW	2
20	BF31016303448		垫片	WASHER	2
21	BF31016250256		护罩架	BRACKET	1
22	BF310167066		螺钉	SCREW	1
23	BF31016210307		波形垫圈	WASHER	1
24	BF31016250257		有机玻璃罩	EYE GUARD	1
25	BF310167009		螺钉	SCREW	2
27	BF31016250225		过线护罩	THREAD TAKE-UP GUARD	1
28	BF31016250226		过线护罩环	FINGER GUARD	1
29	BF310167018		螺钉	SCREW	2
30	BF31016303448		垫片	WASHER	2
31	BF31016250227		过线护罩座	BRACKET	1
32	BF310167018		螺钉	SCREW	2
33	BF31016303448		垫片	WASHER	2
34	BF310167052		螺钉	SCREW	2

三




三、缝台部件/COVER

序号 NO.	品号	CODE	名称	NAME	数量 Number
1	BF310167020		螺钉	SCREW	3
2	BF32026BE0302		缝台	BED COVER	1
3	BF32026BE0303		缝台块	BED COVER	1
4	BF32026BE0304		左盖	TOP COVER	1
5	BF310167020		螺钉	SCREW	3
6	BF32026BE0306		左盖架	SIDE COVER	1
7	BF32026BE0307		销子	PIN	1
8	BF310164554		螺钉	SCREW	2
9	BF32026BE0309		密封垫	GASKET	1
10	BF32026240198		销	PIN	1
11	BF310167009		螺钉	SCREW	2
12	BF32026250263		挡板	BRACKET	1
13	BF310164554		螺钉	SCREW	2
14	BF310167022		螺钉	SCREW	2
15	BF32026201191		垫片	WASHER	3
16	BF32026250013		螺钉	SCREW	1
17	BF32026BE0317		前罩缝台支架 (组件)	BED COVER	1
17-1	BF32026BE0317		缝台支架	ASSEMBLY	1
18	BF32026BE0318		缝台盖板	TOP COVER	1
19	BF310167043		螺钉	SCREW	4
20	BF32026BE0320		销钉	SCREW	1
21	BF31016210025		防震垫	CUSHION	2
22	BF32026BE0322		盖板垫	GASKET	1
23	BF32026250160		盖板	TOP COVER	1
24	BF310167082		螺钉	SCREW	8
25	BF32026BE03173		块	HINGE	1
26	BF310167018		螺钉	SCREW	1
27	BF32026167079		过线	THREAD GUIDE	1

28	BF32026BE0328	过线	THREAD GUIDE	1
29	BF32026BE0329	卡簧	FLAT SPRING	1
30	BF310167019	螺钉	SCREW	1
31	BF140126	螺钉	SCREW	1
32	BF320267018	螺钉	SCREW	1
33	BF310164543	螺钉	SCREW	2

四




四、下轴部件/CRANKSHAFT DRIVE MECHANISM

序号 NO.	品号	CODE	名称	NAME	数量 Number
1	BF32026250551		下轴	CRANKSHAFT	1
2	BF31016057036		螺钉	SCREW	1
3	BF250554-92A		下轴后轴	CRANKSHAFT	1
4	BF320267128		螺钉	SCREW	2
5	BF3202625055991		下轴组件	CRANKSHAFT ASSEMBLY	1
6	BF32026210091		下轴后轴铜连杆组件	CONNECTION	1
7	BF320267015A		螺钉	SCREW	4
8	BF32026252056		下轴球曲柄	CRANK	1
9	BF310164534		螺钉	SCREW	1
10	BF31016250543		蜗杆组件	BUSHING	1
11	BF310164547		螺钉	SCREW	2
12	BF31016250529		轴承套组件	BEARING	1
13	BF310164547		螺钉	SCREW	2
14	BF32026BE0414		下轴同步带轮	GEAR (LOWER)	1
15	BF310164547		螺钉	SCREW	4
16	BF3101625053091		轴承套组件	BUSHING	1
17	BF310164555		螺钉	SCREW	1
18	BF310164547		螺钉	SCREW	1
19	BF310164556		垫圈	WASHER	1
20	BF310164500		螺钉	BOLT	1

五、上轴部件/ARM SHAFT MECHANISM



序号 NO.	品号	CODE	名称	NAME	数量 Number
1	BF32026354B250526C1		针杆曲柄组件	MOTION ASSEMBLY	1
2	BF310164592		螺钉	SCREW	1
3	BF310167028		螺钉	SCREW	1
4	BF310167153		螺钉	SCREW	1
5	BF310167152		螺钉	SCREW	1
6	BF310167268		螺钉	SCREW	2
7	BF32026250560A		上轴	CRANKSHAFT	1
8	BF3101625350092		上轴铜连杆组件	CONNECTION ASSEMBLY	1
9	BF310167015A		螺钉	SCREW	1
10	BF310167015A		螺钉	SCREW	1
11	BF31016253501A		上轴球曲柄	CRANK ASSEMBLY	1
12	BF310164534		螺钉	SCREW	1
13	BF31016250506		接轴套	JOINT	1
14	BF310164555		螺钉	SCREW	1
15	BF310164547		螺钉	SCREW	1
16	BF31016250524		上轴平衡块	BALANCE WEIGHT	1
17	BF310164514		螺钉	SCREW	1
18	BF31016250518		上轴中轴	SHAFT	1
19	BF31016250529		轴承套组件	BUSHING	2
20	BF310164547		螺钉	SCREW	2
21	BF32026BE0521		上轴同步带轮	GEAR (UPPER)	1
22	BF310164547		螺钉	SCREW	1

五



23	BF31016250528	轴承套组件	BUSHING	1
24	BF310164555	螺钉	SCREW	1
25	BF310164547	螺钉	SCREW	1
26	BW0421	手轮	HANDWHEEL	1
27	BF310164541	螺钉	SCREW	1
28	BF310164556	螺钉	SCREW	1
29	BF31016204585	垫片	WASHER	1
30	BF310164501	螺钉	SCREW	1
31	BFBW2560	上轴后轴	SHAFT	1


六



六、针杆部件/NEEDLE BAR/GUARD MECHANISM

序号 NO.	品号	CODE	名称	NAME	数量 Number
1	BF3202625101491		针杆	NEEDLE BAR	1
2	BF31016206061		针杆连接柱	NEEDLE BAR CLAMP	1
3	BF310165325		螺钉	SCREW	1
4	BF32026251016		针杆连杆	LINK	1
5	BF31016206053		针杆连杆销	PIN	1
6	BF31016081212		针杆连杆滚针轴承	NEEDLE BEARING	1
7	BF32026205097		垫圈	WASHER	1
8	BF31016206063		针杆滑块	BLOCK	1
9	BF32026251017		滑块导座	GUIDE	1
10	BF310167020		螺钉	SCREW	2
11	BF32026251018		毛毡弹簧	LATCH	1
12	BF310167021		螺钉	SCREW	1
13	BF3101617904005		毛毡	SPONGE	1
14	BF31016206524		油线托	OIL STRING RETAINER	1
15	BF31016212186		油线	OIL STRING	1
16	BF31016257518		针占	NEEDLE HOLDER	1
17	BF310164554		螺钉	SCREW	3
18	BF310164554		螺钉	SCREW	2
19	BF32026BE0619		针板	NEEDLE PLATE	1
20	BF15082629		螺钉	SCREW	2
21	BF32026BE0621		挡圈	ECCENTRIC	1
22	BF310164543		螺钉	SCREW	2
23	BF32026BE0623		护针曲柄	LEVER	1
24	BF310167086		螺钉	SCREW	1
25	BF32026251512		护针架	NEEDLE GUARD HOLDER (REAR)	1
26	BF32026257567		后护针	NEEDLE GUARD (REAR)	1
27	BF310164543		螺钉	SCREW	1
28	BF32026251513		护线曲柄	LEVER	1
29	BF320267013		螺钉	SCREW	1
30	BF32026251514		护线架	NEEDLE GUARD HOLDER (FRONT)	1
31	BF32026257568		前护针	NEEDLE GUARD (FRONT)	1
32	BF310164543		螺钉	SCREW	1


七



七、弯针部件/LOOPER DRIVE MECHANISM

序号 NO.	品号	CODE	名称	NAME	数量 Number
1	BF3202625203692		凸轮	ECCENTRIC	1
2	BF310164547		螺钉	SCREW	1
3	BF32026263013		滚针轴承	NEEDLE BEARING	1
4	BF32026252035		连杆	ROD	1
5	BF3202625203791		滑杆销	PIN ASSEMBLY	1
6	BF310164805		螺母	NUT	1
7	BF310162400621		垫片	WASHER	1
8	BF32026252039		滑杆架	LOOPER SHAFT GUIDE	1
9	BF31016201074A		止摆轧头	GUIDE	1
10	BF31016202286		弹簧垫片	SPRING WASHER	1
11	BF700S032		螺钉	SCREW	1
12	BF32026252044		下弯针连杆轴	SHAFT	1
13	BF32026240232		垫片	WASHER	1
14	BF8897110		螺栓	BOLT	1
15	SCJ3001		弹簧垫片	SPRING WASHER	1
16	BF32026240231		垫片	WASHER	1
17	BF3202625204692		下弯针曲柄	LEVER	1
18	BF310164534		螺栓	BOLT	1
19	BF32026252040		前挡块	HOLDER	1
20	BF310167021		螺钉	SCREW	1


21	BF32026252041	垫片	WASHER	1
22	BF32026252042	滑块	SLIDER	1
23	BF32026252043	堵头	PIN	1
24	BF310164543	螺钉	SCREW	1
25	BF3202625204592	后挡块	HOLDER	1
26	BF310167021	螺钉	SCREW	1
27	BF32026252041	垫片	WASHER	1
28	BF32026252047	挡块垫片	WASHER	2
29	BF32026252052	后套	BUSHING	1
30	PF1900A0704	螺钉	SCREW	1
31	BF32026B0734	前套	BUSHING ASSEMBLY	1
32	BF32026231011	O形圈	O RING	1
33	PF1900A0704	螺钉	SCREW	1
34	BF32026252048	滑杆	SLIDER	1
35	BF32026252053	弯针架	LOOPER HOLDER	1
36	BF320267145	螺钉	SCREW	1
37	BF32026252055	垫片	WASHER	1
38	BF32026257566	弯针	LOOPER	1
39	BF320267129	螺钉	SCREW	1
40	BF32026240131	弹簧	SPRING	1



八、针距部件/FEED MECHANISM


序号 NO.	品号	CODE	名称	NAME	数量 Number
1	BF3202625260792		送布组件	ECCENTRIC PLUS	1
2	BF310164539		螺钉	SCREW	2
3	BF32026222611		滚针轴承	NEEDLE BEARING	1
4	BF32026242813		滚针轴承	NEEDLE BEARING	1
5	SCJ1039		卡簧	RING	1
6	SCJ1040		卡簧	RING	1
7	BF32026252608		连杆	ROD	1
8	BF32026252609		曲柄	CRANK	1
9	BF310164531		螺钉	BOLT	1
10	BF32026240055		垫圈	WASHER	1
11	BF320267041		螺钉	SCREW	1
12	BF32026252612		偏心连杆	ROD	1
13	BF32026252614		连杆	LINK	1
14	BF32026252615		连杆	LINK	1
15	BF310164543		螺钉	SCREW	2
16	BF32026252613		销子	PIN	2
17	BF889202176		油线	OIL STRING	2
19	BF32026252616		曲柄销	PIN	1
20	BF889202176		油线	OIL STRING	1
22	BF32026252617		曲柄	CRANK	1
23	BF320267142		螺钉	SCREW	2
24	BF3202625261891		曲柄	LINK	1
25	BF310164547		螺钉	SCREW	2
26	BF32026252622		针距调节挡板	GUIDE	1
27	BF310164539		螺钉	SCREW	1
28	BF32026252620		拉簧	SPRING	1
29	BF320267131		螺钉	SCREW	1
30	BF32026252621		针距指示轴	SHAFT	1
31	BF32026240017		O形圈	O RING	2
32	BF32026252623		指示板	LEVER	1
33	BF310167028		螺钉	SCREW	1
34	BF32026252624		刻度板	INDICATION PLATE	1
35	BF320267044		螺钉	SCREW	2
36	BF32026252625		针距调节（杆）组件	SCREW	1
37	SCJ1004		卡簧	RING	1
38	SCJ1006		卡簧	RING	1
39	BF32026240251		O形圈	O RING	1

40	BF320264550	螺钉	SCREW	1
41	BF310164543	螺钉	SCREW	1
42	BF32026252626	垫圈	LINER	1
43	BF32026252660	调节螺母	NUT	1
44	BZ3227	指示板	SEAL	1
45	BF32026233020	O形圈	O RING	1




九、送布部件/FEED MECHANISM

序号 NO.	品号	CODE	名称	NAME	数量 Number
1	BF3202625724316		送布牙	MAIN FEED DOG	1
2	BF3202625729016		差动牙	DIFF FEED DOG	1
3	BF310167082		螺钉	SCREW	1
4	BF310167019		螺钉	SCREW	1
5	BF310167019		螺钉	SCREW	2
6	BF32026BE0906		差动曲柄	DIFFERENTIAL CRANK	1
7	BF8897110		螺钉	SCREW	1
8	BF32026252637		衬套	BUSHING	1
9	BF31016240049		垫片	WASHER	1
10	BF8897056		螺钉	SCREW	1
11	BF32026BE0911		牙架挡板	GUIDE (LEFT)	1
12	BF32026BE0912		定位销	PIN	1
13	BF32026BE0913		差动牙架	DIFFERENTIAL BRACES	1
14	BF32026BE09131		差动牙架（35）	DIFFERENTIAL BRACES	1
15	BF32026BE0914		送布牙架	FEED DOG STAND	1
16	BF32026BE0915		滑块	BLOCK	1
17	BF32026BE0916		抬压轴	CRANKSHAFT	1
18	BF32026BE0917		连杆	LINK	1
19	BF32026BE0918		衬套	BUSHING	1
20	BF32026BE0919		螺钉	SCREW	1
21	BF310164500		螺钉	SCREW	1
22	BF32026BE0921		螺钉	SCREW	1
23	BF32026BE0922		锥形垫片	WASHER	1
24	BF32026BE0923		连接销	PIN	1
25	BF32026BE0924		差动摆动曲柄	LINK	1
26	BF32026252636		差动连杆	LINK	1
27	BF32026BE0926		销	PIN	1
28	BF310164500		螺钉	SCREW	1
29	BF32026BE0928		曲柄	LINK	1
30	BF32026BE0929		差动轴	SHAFT	1
31	BF32026202175		油线	OIL STRING	1
32	SCJ6029		针销	PIN	1
33	BF32026202177		油线	OIL STRING	1
34	BF32026252632		抬压滑块	BLOCK	1
35	BF700K091213		滚针	NEEDLE BEARING	1
36	BF32026252628		右挡板	GUIDE (RIGHT)	1
37	PF1900A0704		螺钉	SCREW	1
38	BF32026240239		挡圈	COLLAR	1
39	BF310164547		螺钉	SCREW	1
40	BF3202624023592		挡块	COLLAR	2
41	BF310164547		螺钉	SCREW	2
42	BF310167028		螺钉	SCREW	1
43	BF310164805		螺母	NUT	1
44	BF32026204052		油封	OIL SEAL	1
45	BF32026240241		油封	OIL SEAL	1
46	BF32026938		抬压轴前套	BUSHING	2
47	BF32026940		抬压轴后套	BUSHING	1
48	BF32026941		送布轴前套（差动）	BUSHING	1
49	BF32026942		送布轴后套（差动）	BUSHING	1
50	BF310164554		螺钉	SCREW	1
51	BF31016303448		垫片	WASHER	2
51	BF31016303448		垫片	WASHER	2




十、压脚部件/PRESSER FOOT MECHANISM

序号 NO.	品号	CODE	名称	NAME	数量 Number
1	BF31016253000		调压螺杆（组件）	ADJUSTING BAR	1
2	BF32026253003		调压螺母	NUT	1
3	BF32026240252		调压簧	SPRING	1
4	BF31016240113		压脚轴小弹簧	SPRING	1
5	BF32026253026		压脚轴	PRESSER BAR	1
6	BF31016253018		压脚轴密封垫	OIL SHIELD	2
7	BF31016206139		压脚轧头	PRESSER BAR CLAMP	1
8	BF310165118		螺钉	SCREW	1
9	BF31016253005		导块	GUIDE	1
10	BF310167025		螺钉	SCREW	2
11	BF310167010		螺钉	SCREW	1
12	BF31016202875		垫片	WASHER	1
13	BF31016253008		杠杆	LEVER	1
14	BF31016192024		挡圈	COLLAR	1
15	BF31016W00301		螺钉	SCREW	1
16	BF31016206157		压脚轧头连接板	LINK	1
17	BF310165386		螺钉	SCREW	2
18	BF32026253010		抬压轴簧	SPRING	1
19	BF31016206156		挡圈	COLLAR	1
20	BF310165084		螺钉	SCREW	2
21	BF31016206149		抬压曲柄 I	BELL CRANK (UPPER)	1
22	BF310165187		螺钉	SCREW	1
23	BF32026253027		抬压曲柄连接板	LINK	1
24	BF310165184		螺钉	SCREW	1
25	BF31016206148		抬压曲柄 II	BELL CRANK (LOWER)	1
26	BF310162022		螺钉	SCREW	1
27	BF31016253013		抬压轴	SHAFT	1
28	BF31016253014		抬压轴扳手	LEVER	1
29	BF310167028		螺钉	SCREW	1
30	BF31016253015		支板	BRACKET	1
31	BF310167019		螺钉	SCREW	2
32	BF310164549		螺钉	SCREW	1
33	BF310164805		螺母	NUT	1
34	BF31016253028		压脚护罩	FINGER GUARD	1
35	BF31016257461		压脚	PRESSER FOOT ASSEMBLY	1
36	BF3101611703		螺钉	SCREW	1
37	BF31016240585		油封	OIL SEAL	1
38	BF320261123		压脚轴套	BUSHING	1
39	BF310161142		抬压脚轴套	BUSHING	1




十一、喂针部件/SPREADER MECHANISM

序号 NO.	品号	CODE	名称	NAME	数量 Number
1	BF31016254501A		偏心凸轮	ECCENTRIC ASSEMBLY	1
2	BF310164514		螺钉	SCREW	2
3	BF31016254511		偏心连杆	CONNECTION	1
4	BF31016254503		偏心摆动曲柄	CRANK	1
5	BF310164534		螺钉	BOLT	1
6	BF31016254504		连杆销	SCREW	1
7	BF310162400621		垫片	WASHER	1
8	BF310164805		螺母	NUT	1
9	BF31016254519		摆动连杆轴	SHAFT	1
10	BF31016206180		垫圈	WASHER	1
11	SCJ1014		卡簧	RING	1
12	BF31016254506		偏心摆动连杆	CRANK	1
13	BF310164547		螺钉	SCREW	2
14	BF31016254507		偏心摆动销	BLOCK	1
15	BF32026254518		偏心竖轴	CRANKSHAFT	1
17	BF889202176		油线	OIL STRING	1
18	BF31016210586		油封	OIL SEAL	1
19	BF31016212039		挡圈	COLLAR	1
20	BF310167010		螺钉	SCREW	2
21	BF31016254516		偏心架	LEVER ASSEMBLY	1
22	BF310167020		螺钉	SCREW	1
23	BF310167021		螺钉	SCREW	1
24	BF31016257565		偏心	SPREADER	1
25	BF31016240584		垫片	WASHER	1
26	BF320261218		偏心轴套	BUSHING	1
27	BF310161230		偏心摆动连杆轴套	BUSHING	2



十二、松线部件/THREAD TENSION MECHANISM


序号 NO.	品号	CODE	名称	NAME	数量 Number
1	BF31016254022		松线轴	LEVER	1
2	BF31016254022		轴套	COLLAR	1
3	BF310162133		螺钉	SCREW	1
4	BF31016254003B		松线曲柄	CRANK	1
5	BF310164531		螺钉	BOLT	1
6	BF31016202868		垫片	WASHER	1
7	BF31016254008		过线架	THREAD GUIDE	1
8	BF310167019		螺钉	SCREW	2
9	BF31016192120		夹带杆	PIPE	2
10	BF31016254009		压板	BRACKET	1
11	BF320267018		螺钉	SCREW	1
12	BF31016303448		垫片	WASHER	1
13	BF31016254010B9U		3针5线夹线器组件	TENSION CONTROL MECHANISM	1
14	BF31016254019		过线板	BRACKET	1
15	BF31016254021		过线调节板	THREAD RELEASER	1
16	BF31016254010B9U		调线组件（中）	TENSION SPRING ASSEMBLY	1
17	BF31016254010C9U		调线组件（弱）	TENSION SPRING ASSEMBLY (LIGHT)	1
18	BF31016306301		调节板簧	SPRING	1
19	BF310165447		螺钉	SCREW	1
20	BF31016254010A9U		调线组件（强）	TENSION SPRING ASSEMBLY (HEAVY)	3
21	BF31016254020		二孔过线板 I	THREAD GUIDE	5
22	BF31016206203		二孔过线板 II	THREAD GUIDE	5
23	BF31016206202		垫圈	SPACER	5
24	BF310167019		螺钉	SCREW	2
25	BF310161817-2A		夹线钉	SCREW STUD	5
26	BF31016210319		夹线片	TENSION DISC	10
27	BF31016208450-UA		调压止动盖	CLIP	5
28	BF31016201037		调压簧（强）	SPRING (HEAVY)	3
29	BF31016201086		调压簧（中）	SPRING (MEDIUM)	1
30	BF31016201068		调压簧（弱）	SPRING (LIGHT)	1
31	BF31016208448		调压止动套	RATCHET	5
32	BF31016208447-UA		调压螺母	NUT	5



十三、过线部件/NEEDLE&SPREADER THREAD HANDLING

序号 NO.	品号	CODE	名称	NAME	数量 Number
1	BF31016240201		挡圈	COLLAR	1
2	BF310165084		螺钉	SCREW	2
3	BF31016253503		过线座轴	SHAFT	1
4	BF31016204107		垫片	WASHER	1
5	SCJ3001		弹簧垫圈	SPRING WASHER	1
6	BF310164527		螺栓	BOLT	1
7	BF700M83		油封	OIL SEAL	1
8	BF31016240102		垫片	WASHER	1
9	BF31016253504		过线座	LEVER	1
10	BF310164501		螺栓	BOLT	1
11	SCJ3003		弹簧垫圈	SPRING WASHER	1
12	BF31016253505		长过线	THREAD TAKE-UP	1
13	BF310167019		螺栓	SCREW	2
14	BF31016303448		垫圈	WASHER	2
15	BF31016253507		三孔过线	THREAD GUIDE	1
16	BF310167010		螺栓	SCREW	1
17	BF31016253508		过线板	THREAD GUIDE	1
18	BF310167077		螺栓	SCREW	1
19	BF31016253509		护线罩	THREAD SUPPORT	1


20	BF31016202588	垫片	WASHER	1
21	BF310167010	螺钉	SCREW	1
22	BF31016253544	硅油盒固定架	THREAD GUIDE	1
23	BF310167019	螺钉	SCREW	1
24	BF31016303448	垫圈	WASHER	1
25	BF31016253545	针杆过线座	HOLDER	1
26	BF31016234521	过线杆	THREAD GUIDE	1
27	BF310164535	螺钉	SCREW	3
28	BF310167010	螺钉	SCREW	2
29	BF31016253516	U形夹线座	THREAD TENSION BRACKET	1
30	BF310167019	螺钉	SCREW	1
31	BF31016234561	夹线板	THREAD GUIDE	1
32	BF31016253593	夹线片	TENSION DISC	1
33	BF31016253517	弹簧	SPRING	1
34	BF31016W90702	螺钉	SCREW	1
35	BF31016253506	长过线压板	THREAD TAKE-UP	1
36	BF31016253515	过线板	THREAD GUIDE	1
37	BF310167019	螺钉	SCREW	1
38	BF31016253514	细针过线	THREAD GUIDE	1
39	BF310167019	螺钉	SCREW	2
40	BF31016253548	细针过线板	THREAD GUIDE	1
41	BF310167019	螺钉	SCREW	2
42	BF31016303448	垫片	WASHER	2
43	BF31016253547	细针二孔过线	THREAD GUIDE	1
44	BF310167167	夹线螺钉	SCREW	1
45	BF31016137108	夹线片	TENSION DISC	2
46	BF31016211388	弹簧	SPRING	1
47	BF31016253511	细针小过线	THREAD GUIDE	1
48	BF310164554	螺钉	SCREW	1
50	BF31016275034	螺母	KNOB	1
51	BF31016835	弯针过线轴套	BUSHING	2



十四、打线凸轮部件/LOOPER THREAD HANDLING


序号 NO.	品号	CODE	名称	NAME	数量 Number
1	BF32026BE1401		销	PIN	2
2	BF310167009		螺钉	SCREW	3
3	BF32026BE1403		打线片	THREAD GUIDE	1
4	BF31016005		过线片（右）	THREAD GUIDE	1
5	BF31016004		过线片（左）	THREAD GUIDE	1
6	BF32026BE1406		复位弹簧	SPRING	1
7	BF32026BE1407		打线架扳手	FIGHT LINE WRENCH	1
8	BF32026BE1408		轴位螺钉	SCREW	1
9	BF32026BE1409		挡块	STOP	1
10	BF32026BE1410		打线架	BRACKET	1
11	BF32026BE1411		打线架挡圈	FIGHT LINE RETAINING RING	1
12	BF32026BE1412		复位弹簧	SPRING	1
13	BF310167023		螺钉	SCREW	1
14	BF32026BE1414		卡簧片	SPRING	1
15	BF320267018		螺钉	SCREW	1
16	BF32026BE1416		轴位螺钉	SCREW	1
17	BF32026BE1417		打线凸轮	LOOPER THREAD TAKE-UP	1
18	BF310164543		螺钉	SCREW	2
19	BF32026BE1419		挡圈	COLLAR	1
20	BF32026BE1420		轴承G6902Z	BEARING	2
21	BF32026BE1421		轴承套	BUSHING	2
22	BF310164547		螺钉	SCREW	6
23	BF32026BE1423		小同步带	SMALL TIMING BELT	1
24	BF32026BE1424		小同步轮	TIME BELT	1
25	BF32026BE1425		凸轮轴	SHAFT	1
26	BF8004533		螺钉	SCREW	4
28	BF320267018		螺钉	SCREW	2
29	BF32026BE1429		盖板	COVER	1
30	BF32026BE1430		凸轮座	CAM SEAT	1
31	BF310167167		调压螺钉	SCREW	1

32	BF31016211388	夹线簧	SPRING	1
33	BF31016137108	夹线片	THREAD RETAINER	2
34	BF32026BE1434	过线	THREAD GUIDE	1
35	BF310167079	螺钉	SCREW	1
36	BF32026BE1436	托板	LAYER	1
37	SCJ3016	波形垫片	WASHER	2
38	BF32026BE1438	密封垫	CAM GASKET	1
39	BF32026BE1439	盖板	COVER	1
40	BZ3096	机型牌	STICKER	1
41	BF310167018	螺钉	SCREW	4
42	SCJ6071	铆钉	PIN	2
43	BF32026BE1443	护罩	SHIELD	1
44	BF31016275034	调压螺母	ADJUSTING NUT	1
46	BF310161371081	羊毛毡	STICKER	1




十五、供油部件（1）/LUBRICATION MECHANISM(1)

序号 NO.	品号	CODE	名称	NAME	数量 Number
1	BF32026BE1501		喷油管	PIPE	1
2	BF31016255037		过油螺钉	JOINT SCREW	1
3	SCJ5012		油管	TUBE	1
4	BF310162001361		油管接头	JOINT	2
5	BF31016202199		油管夹	CLAMP	2
6	BF700S063		过油螺钉	JOINT SCREW	2
7	BF31016255003		铜油管	PIPE	1
8	BF31016240136		油毡	FELT	1
9	SCJ6029		大头针	PIN	1
10	BF310164514		螺钉	SCREW	1
11	BF31016255021		油毡	FELT	1
12	BF31016255005		压簧	LATCH	1
13	BF320267018		螺钉	SCREW	1
14	SCJ5010		油管套	TUBE	1
15	SCJ5010		油管	TUBE	1
16	BF31016255038		接头	JOINT	1
17	SCJ5012		油管	TUBE	1
18	BF31016202199		油管夹	CLAMP	4
19	BF32026255099		接油盘	OIL RELEASE PLATE	1
20	BF320267018		螺钉	SCREW	2
21	BF31016255007		喷油管	OIL SPLASH PIPE	1
22	BF310164821		螺母	NUT	1
23	SCJ5012		油管	TUBE	1
24	BF31016202199		油管夹	CLAMP	2
25	BF3202625509491		喷油管	OIL SPLASH PIPE	1
26	BF310162001362		油管接头	JOINT	1
27	BF32026200152		过油螺钉	JOINT SCREW	1
28	BF31016202199		油管夹	CLAMP	1
29	BF32026255100910		吸油管	OIL DRAIN PIPE	1
30	BF32026255102		吸油管	PIPE	1
31	BF320267017		螺钉	SCREW	1
32	SCJ5012		油管	TUBE	1
33	BF141126		油管夹	CLAMP	1
34	BF32026240245		油毡	FELT	1
35	SCJ5010		油管	TUBE	1
36	SCJ5010		油管	TUBE	1
37	BF320267018		螺钉	SCREW	1
38	BF32026255039		油管	TUBE	1
39	SCJ5012		油管	TUBE	1




十六、供油部件（2）/LUBRICATION MECHANISM(2)

序号 NO.	品号	CODE	名称	NAME	数量 Number
1	BF32026255041		油盘	OIL RESERVOIR ASSEMBLY	1
2	BF800202287A		油封	WASHER	1
3	BF8005318B		放油螺钉	SCREW	1
4	BF310164504		螺钉	BOLT	4
5	BF32026255144		油盘密封圈	O RING	1
6	BF32026BE1606		油泵组件	OIL PUMP ASSEMBLY	1
7	BF32026255024		油泵轴	SHAFT	1
8	BF32026255025		五星轮	ROTOR	1
9	BF32026255026		五星轮	ROTOR	1
10	BF32026255027		五星套	ROTOR	1
11	BF32026255028		油泵盖	COVER	1
12	BF320267026		螺钉	SCREW	2
13	BF320267105		螺钉	SCREW	2
14	BF32026255019		油泵蜗轮	WORM WHEEL	1
15	BF320264514		螺钉	SCREW	2
16	BF310164531		螺钉	BOLT	2
17	BF31016200152A		油管接头	JOINT SCREW	2
18	BF700M156		滤油器	OIL FILTER	1
19	BF31016210200		螺钉	OIL FILTER BRACKET	1
20	BF31016206431		O形圈	O RING	1
21	BF31016210201		滤油器盖	COVER	1
22	BF310167021		螺钉	SCREW	3
23	BZ3153		警告标贴	FILTER SEAL	1
24	BF31016200152A1		油管接头	JOINT	1




十七、硅油盒装置部件/HR DEVICE

序号 NO.	品号	CODE	名称	NAME	数量 Number
2	BF31016207066		上硅油盒	SILICONE OIL RESERVOIR (UPPER)	1
3	BF31016207067		下硅油盒盖	CAP	1
4	SCJ4023		开口销	SPRING PIN	2
5	SCJ2035		木螺钉	SCREW	2
6	BF31016207068		硅油棉	FELT	1
7	BF32026BE1707		下硅油盒	SILICONE OIL RESERVOIR ASSEMBLY	1
8	BF310167020		螺钉	SCREW	2
9	BF32026255107		机针冷却器	NEEDLE COOLER (LOWER)	1
10	BF310167019		螺钉	SCREW	1
11	BF32026240247		硅油棉	FELT	1
12	SCJ6029		大头针	PIN	1
13	SCJ5010		油管	TUBE	1
14	BF32026202175		油线	OIL STRING	1
16	BF32026BE1716		硅油盒挡板	SILICONE OIL BOX BAFFLE	1
17	BF32026BE1717		硅油盒上盖	SILICONE OIL BOX COVER	1



第十八、油盘托板部件/INSTALLATION PARTS


序号 NO.	品号	CODE	名称	NAME	数量 Number
2	BF310162063381		油盘减振垫	CUSHION RUBBER	4
3	BF31016206336		螺钉固定头	NUT	4
4	BF31016259000		承重板	REST BOARD	2
5	BF310164512		螺钉	BOLT	4
6	BF31016206337		垫圈	WASHER	12
7	BF700M186		连接套	CUSHION RUBBER	4
8	BF32026205765		减振垫套	LINER	4
9	BF310167093		螺钉	SCREW	4
10	BF31016206329		卡板	TREADLE CHAIN GUIDE	1
11	BF310167027		螺钉	SCREW	2
12	BF31016205467		减振垫	SPACER	4
14	BF310162063381		油盘减振垫	CUSHION RUBBER	4
15	/		螺钉组件	SCREW	4
16	BF32026207073		支柱	SCREW	4
17	BF32026207074		卡簧	RING	4
18	SCJ3023		垫圈	WASHER	4
19	SCJ3006		弹簧垫圈	SPRING WASHER	4
20	BF320265020		螺母	NUT	4
21	BF32026259003TBO		皮带护罩	BELT COVER	1
22	SCJ2037		木螺钉	SCREW	3



十九、线架部件/THREAD STAND

序号 NO.	品号	CODE	名称	NAME	数量 Number
1	BF7005M17		线架组件(五线)	THREAD STAND ASSY.	1
2	BF889502-PA		线架上棒	COLUMN PIPE (UPPER)	1
3	BF889503-PA		线架下棒	COLUMN PIPE (LOWER)	1
4	BF889504-PA		锁紧卡固	JOINT	1
5	BF8894012		螺钉	SCREW	2
6	BF8894803		螺母	NUT	2
7	BF889527-PA		长过线架	BRACKET	1
8	BF889527APA		短过线架	BRACKET	1
9	BF8891160		固定板	HOLDER	2
10	BF8894068-HU		螺钉	SCREW	2
11	BF889380A		线棒	SPOOL PIN	5
12	BF889201252		垫片	SPRING WASHER	5
13	BF8894803		螺母	NUT	5
14	BF889381-PA		线托盘	SPOOL TRAY	5
15	BF889507		托盘垫	SPOOL MAT	5
16	BF889382-PA		线固定套	SPOOL RETAINING FIN	5
17	BF889383-PA		棒架	BRACKET	1
18	BF8894014		螺钉	SCREW	1
19	BF8894803		螺母	NUT	1
20	BF889384		线棒	THREAD GUIDE BAR	1
21	BF8894012		螺钉	SCREW	1
22	BF8894803		螺母	NUT	1
23	BF889233-PA		固定器	BRACKET	1
24	BF8894012		螺钉	SCREW	1
25	BF8894803		螺母	NUT	1
27	BF889293A		过线棒	THREAD GUIDE BAR	1
28	BF8894012		螺钉	SCREW	1
29	BF8894803		螺母	NUT	1
30	BF889527-PA		长线架	BRACKET	1
31	BF889527APA		短线架	BRACKET	1
32	BF8891160		固定板	HOLDER	2
33	BF8894068-HU		螺钉	SCREW	2
34	BF889506		过线套	THREAD GUIDE	5
35	BF889386		棒帽	ROD CAP	1
36	BF889509		垫片	WASHER	2
37	BF8891170		弹性垫片	SPRING WASHER	1
38	BF8894835		螺母	NUT	1


二十



二十、缝台部件/Front Cover Assembly

序号 No.	品号	CODE	名称	NAME	数量 Number
1	BF32026240198		销	PIN	1
2	BF310167009		螺钉	SCREW	2
3	BF32026250263		垫块	BRACKET	1
4	BF320264554		螺钉	SCREW	2
5	BF310167023		螺钉	SCREW	2
6	BF32026201191		垫片	WASHER	1
7	BF32026250013		缝台座螺钉	SCREW	2
8	BF32026BE0317		前置缝台支架组件	BED COVER	1
8-1	BF32026BE03171		缝台支架	ASSEMBLY	1
9	BF32026BE0318		缝台盖板	TOP COVER	1
10	BF310167043		螺钉	SCREW	4
11	BF32026BE0320		销钉	PIN	1
12	BF31016210025		防震垫	CUSHION	2
13	BF3202625709703FB56		针板	NEEDLE PLATE	1
14	BF3202625910316		主动牙 (03FB)	MAIN FEED DOG	1
15	BF3202625921516		差动牙 (03FB)	DIFF. FEED DOG	1
16	BF32026257569		左牛角	FABRIC GUIDE (LEFT)	1
17	BF32026257570		右牛角	FABRIC GUIDE (RIGHT)	1
18	BF3202625710556		针板	NEEDLE PLATE	1
19	BF3202625724316		送布牙	MAIN FEED DOG	1
20	BF3202625921216		差动牙 (03GB)	DIFF. FEED DOG	1
21	BF32026257575		左牛角	FABRIC GUIDE (LEFT)	1
22	BF32026257576		右牛角	FABRIC GUIDE (RIGHT)	1


二十一



二十一、02专用件/SPECIFIC PARTS

序号 No.	品号	CODE	名称	NAME	数量 Number
1	BF32026BE2101		缝台组件 (02型)	FRONT COVER ASSEMBLY	1
2	BF32026BE2102		缝台块 (02型)	BED COVER	1
3	BF32026BE2103		挡板座 (02型)	HINGE	1
4	BF32026BE2104		挡板 (02型)	AUXILIARY PLATE (FRONT COVER)	1
5	BF32026BE2105		挡料片 (02型)	FABRIC GUARD	1
6	BF32026BE2106		缝台小盖板 (02型)	COVER	1
7	BF32026BE2107		支架 (02型)	BRACKET	1
8	BF32026BE2108		缝台盖板	TOP COVER	1
9	BF32026BE2109		缝台支架	BED COVER	1
9-1	BF32026BE21091		缝台支架座	HINGE	1
10	BF310167043		螺钉	SCREW	3
11	BF320267017		螺钉	SCREW	2
12	BF8007008		螺钉	SCREW	2
13	BF310167009		螺钉	SCREW	2
14	BF310167043		螺钉	SCREW	1
15	BF310167019		螺钉	SCREW	1
18	BF3101602BB206460		压板	WASHER	1
19	BF310167027		螺钉	SCREW	2
20	BF32026250189		压板	WASHER	1
21	BF320265113		螺钉	SCREW	2
22	BF320267027		螺钉	SCREW	1
23	BF32026240042		垫片	NUT	1
24	BF3101602BBTB		托盘组件	TAPE GUIDE ASSY.	1
25	BF31016247-SA		托盘	TAPE BASE	1
26	BF31016270		垫片	WASHER	1
27	BF31016253		上棒	PIN	1
28	BF31016250		下棒	TAPE DISC POST	1
29	BF310161448		螺钉	SCREW	1
30	BF310160251-SA		托盘座	BRACKET	1
31	BF310164913		木螺钉	SCREW	3
32	BF31016252		螺栓	SCREW	2
33	BF31016204585		弹性垫片	WASHER	2
34	BF31016303067		螺母	SPRING WASHER	2
35	BF31016226		垫片	NUT	2
36	BF31016253		短棒	PIN	2
37	BF31016254		座	HOLDER	2
38	BF310165161		螺钉	SCREW	4
39	BF31016255		导棒	TAPE GUIDE BAR	1
40	BF310164012		螺钉	SCREW	2
41	BF310164803		螺母	NUT	2
42	BF31016256-SA		导棒座	HOLDER	1
43	BF3101602BB257321		压脚	PRESSER FOOT ASSEMBLY	1
44	BF3101602BB257033		针板	NEEDLE PLATE	1
45	BF3202625724616		主动牙	MAIN FEED DOG	1
46	BF3202625729316		差动牙	DIFF. FEED DOG	1

二十二




二十二、35专用件 (1) /SPECIFIC PARTS

序号 No.	品号	CODE	名称	NAME	数量 Number
1	BF3202635AR255552		曲柄	CRANK	1
2	BF310164547		螺钉	SCREW	2
3	BF3202635AB7057		螺钉	SCREW	1
4	BF31016240049		垫圈	WASHER	3
5	BF889240542A		轴套	BUSHING	1
6	BF3202635AR255553		螺母	NUT	1
7	BF3202635AR255554		曲柄	CRANK	1

8	BF310164547	螺钉	SCREW	1
10	BF3202635AR255557A	连杆	LINK	1
11	BF32026202174	油线	OIL STRING	1
12	BF32026202175	油线	OIL STRING	1
13	BF3202635AR255077	卡板	LATCH	1
14	BF3202635AB7061	螺钉	SCREW	1
15	BF3202635AR255555	轴	SHAFT	1
16	BF3202635AR230030	垫圈	WASHER	1
17	BF3101605306105	弹簧	SPRING	1
18	BF3202635AR255546	螺母	NUT	1
19	BF3202635AR255549	座	BRACKET ASSEMBLY	1
20	BF310164501	螺钉	SCREW	2
21	BF3202635AB4502	螺钉	SCREW	1
23	BF3202635AR2555491	上刀座	UPPER KNIFE HOLDER ASSEMBLY	1
24	BF310167028	螺钉	SCREW	1
25	BF3202635AR257574	上刀	UPPER KNIFE	1
26	BF3202635AB7062	螺钉	SCREW	1
27	BF3202635AR255560	下刀座	LOWER KNIFE HOLDER	1
28	BF3202635AB7030	螺钉	SCREW	1
29	BF3202635AB204161A	下刀	LOWER KNIFE	1
30	BF3202635AR2555891	下刀压板	LOWER KNIFE CLAMP ASSEMBLY	1
31	BF700S050	螺钉	SCREW	1
32	BF3202635AR255615	挡板	WASTE CHUTE TOP	1
33	BF8007012	螺钉	SCREW	2
34	BF32026BE2234	排料管	SUCTION PIPE ASSEMBLY	1
35	SC16035	紧箍	HOSE BAND	1
36	BF32026BE2236	固定板	LATCH	1
37	BF310167082	螺钉	SCREW	2
38	SC16034	气管接头	JOINT	1
39	BF32026BE2239	拍牙轴	SHAFT	1
41	BF3202635AR25541	铜套 (左)	BUSHING	1
42	BF3202635AR2542	铜套 (右)	BUSHING	1

二十三




二十三、35专用件 (2) /SPECIFIC PARTS

序号 No.	品号	CODE	名称	NAME	数量 Number
1	BF3202635AR250526C1		针杆曲柄 (组件)	MOTION ASSY.	1
2	BF310167028		螺钉	SCREW	2
3	BF310164592		螺钉	SCREW	1
4	BF32026250517A		上轴	CRANKSHAFT	1
5	BF3202635AR251010A		偏心销	ECCENTRIC PIN	1
6	BF32026205097		垫圈	WASHER	1
7	BF320267041		螺钉	SCREW	1
8	BF32026BE2308		缝台块 (35型)	SLIDE PLATE	1
9	BF3202635AR257577A		挡板	HEMMING GUIDE	1
10	BF320267017		螺钉	SCREW	1
11	BF3202635AR257578		挡板	HEMMING GUIDE	1
12	BF310167018		螺钉	SCREW	1
13	BF31016303448		垫片	WASHER	1
14	BF32026BE2314		缝台盖板	AUXILIARY PLATE (FRONT COVER)	1
15	BF310167043		螺钉	SCREW	3
16	BF3202635AR257743A		压脚辅助板	FABRIC GUIDE	1
17	BF2C2315		螺钉	SCREW	2
18	BF320262520531		弯针架	LOOPER HOLDER	1
19	BF32026BE2319		前罩缝台支架组件	FRONT COVER ASSEMBLY	1
20	BF32026250013		螺钉	SCREW	1
21	BF32026201191		垫圈	SPRING WASHER	2
22	BF32026240198		销	PIN	1

23	BF320264554	螺钉	SCREW	2
24	BF32026BE2324	针板座	BRACKET	1
27	BF32026BE2327	左盖 (35型)	CLOTH PLATE ASSEMBLY	1
28	BF32026BE2328	针板	NEEDLE PLATE	1
29	BF32026BE2329	送牙齿	MAIN FEED DOG	1
30	BF32026BE2330	差动牙	DIFF FEED DOG	1


二十四



二十四、RP专用件 (1) /SPECIFIC PARTS

序号 No.	品号	CODE	名称	NAME	数量 Number
1	BF32026256500		RP凸轮	ECCENTRIC	1
2	BF310164555		螺钉	SCREW	2
3	BF310164547		螺钉	SCREW	2
4	BF32026256501		RP连杆	CONNECTION	1
5	BF32026242813		滚针	NEEDLE BEARING	1
6	BF32026256502		RP连杆盖	COLLAR	1
7	BF310164547		螺钉	SCREW	2
8	BF32026256503		RP曲柄	CRANK	1
9	BF310164547		螺钉	SCREW	2
10	BF31016254504		连杆销	SCREW	1
11	BF310162400621		垫片	WASHER	1
12	BF310164805		螺母	NUT	1
13	BF889240308		挡圈	COLLAR	1
14	BF310164554		螺钉	SCREW	2
15	BF32026256504		RP后窗盒	BRACKET ASSEMBLY	1
16	BF32026256507		RP油封圈	O RING	1
17	BF32026256508		RP密封塞	PLUG	1
18	BF8894523		螺钉	BOLT	4
19	BF700M513		RP油封	OIL SEAL	1
20	BF32026256509		RP横轴	SHAFT	1
21	BF31016206180		垫片	WASHER	1
22	SC11014		卡簧	RING	1
23	BF32026211247		RP密封塞	PLUG	1
24	BF32026256536		支撑座	BRACKET ASSEMBLY	1
25	BF32026256545		U型轴	GUIDE BAR	1
26	PF1790S0136		螺钉	BOLT	2
27	BF320264514		螺钉	SCREW	2
28	BF32026256546		压板	COVER	1
30	BF320267062		螺钉	SCREW	2
31	BF32026256540		齿轮	LOWER TOOTHED ROLLER	1
34	BF32026256522		连杆板	CONNECTING PLATE	1
35	BF32026256523		压板	LEVER	1
36	BF320267141		螺钉	SCREW	2
37	BF32026306789		垫片	CUSHION RUBBER	2
38	BF310167079		螺钉	SCREW	2
39	BF320264821		螺母	NUT	2
40	BF32026RP1		RP铜套1	BUSHING	1
41	BF32026RP2		RP铜套2	BUSHING	1


二十五



二十五、RP专用件 (2) /SPECIFIC PARTS


序号 NO.	品号	CODE	名称	NAME	数量 Number
1	BF32026256510		压脚架	BRACKET ASSEMBLY	1
2	BF32026256512		调节螺钉	SCREW	1
3	BF8004510		螺钉	BOLT	2
4	BF32026256518		轴	SHAFT	1
5	BF32026202901		卡簧	RING	1
7	BF32026240257		弹簧	SPRING	1
8	BF32026256517		压板	BRACKET	1
9	BF320264510		螺钉	BOLT	1
10	BF320267025A		螺钉	SCREW	1
11	BF320264821		螺母	NUT	1
12	BF32026256519		压板	LINK	1
13	BF320267066		螺钉	SCREW	2
14	BF32026306789		垫片	CUSHION RUBBER	1
15	BF32026256520		曲柄	LEVER	1
16	BF32026256521		螺钉	SCREW	1
17	BF32026256524		调节板	LEVER	1
18	BF32026256527		螺钉	SCREW	1
19	BF32026240258		弹性垫片	WASHER	1
20	BF32026256529		调节板	GUIDE PLATE	1
21	BF320267068		螺钉	SCREW	2
22	BF32026256530		销子	SHAFT	1
23	BF320264514		螺钉	SCREW	1
24	BF32026256531		连杆板	CRANK	1
25	BF320267083		螺钉	SCREW	3
26	BF32026256533		卡簧	FLAT SPRING	1
27	BF32026256528		压轮架	BRACKET	1
28	BF320264510		螺钉	BOLT	1
29	BF320264539		螺钉	SCREW	1
30	BF32026256532		轴	SHAFT	1
31	BF32026240259		垫片	WASHER	1
32	BF32026240102		垫片	WASHER	1
33	BF320267140		螺母	NUT	1
34	BF320264568		螺钉	SCREW	1
35	BF32026256548		挡板	COVER	1
36	BF320267074		螺钉	SCREW	2
37	BF320267068		螺钉	SCREW	2
38	BF32026256012		棘轮	CLUTCH	2
39	BF32026306500		销子	PIN	6
40	BF32026306243		螺钉	GUIDE PLATE	6
41	BF32026240114		弹簧	SPRING	12
42	BF320267083		螺钉	SCREW	3
43	BF32026256535		压板	CLUTCH PLATE	1
44	BF32026256550		棘轮套	SLEEVE ASSEMBLY	1
45	BF320267139		螺钉	SCREW	1
46	BF320264539		螺钉	SCREW	1
47	BF32026256558		螺母	NUT	1
48	BF32026256513		曲柄	CRANK	1
49	BF320264534		螺钉	BOLT	1
50	BF32026256514		调节销	PIN	1
51	BF32026137441		垫片	WASHER	2
52	BF32026256515		轴套	BUSHING	2
53	BF32026240011		滚针	NEEDLE BEARING	2
54	BF32026256516		连杆	LINK	1
55	BF320264805		螺母	NUT	2
56	BF32026137441		垫片	WASHER	1

57	BF320267138	螺钉	BOLT	1
58	BF32026256543	橡胶轮	UPPER ROLLER	1
59	BF32026256538	齿轮	UPPER TOOTHED ROLLER	1
61	BF320267083	螺钉	SCREW	3
62	BF32026HTL	后拖轮组件	PULLER ASS'Y	1



二十六、电机部件


序号 NO.	品号 CODE	名称	NAME	数量 Number
1	BFW2561	下轴后轴	SHAFT	1
2	W2CDJZJ-1	电机座	BASE	1
3	W2CDJZJ-2	定子转子	MOTOR ROTOR	1
4	W2CDJZJ-3	螺钉	SCREW	4
5	W2CDJZJ-4	电机	MOTOR STATOR	1
6	BFW2560	上轴后轴	SHAFT	1
7	BW2CTMP	W2C编码盘	CODING DISC	1
8	BFP1CDK	主电控	CONTROLLER	1
9	SCJ2004	螺钉	SCREW	5
10	BW0421	上手轮	HAND WHEEL	1
11	BW0422	下手轮	HAND WHEEL	1



二十七、剪线电磁铁与下剪刀


序号 NO.	品号 CODE	名称	NAME	数量 Number
1	BF32026KE355/DM	压板	PLATE	1
2	BF32026KE356/DM	压板	PLATE	1
3	BF32026007018A/P	螺钉	SCREW	2
4	BF32026TE1299	螺钉	SCREW	1
5	BF32026P/W600EUT-001-001	刀盘	CUTTER HEAD	1
6	BF32026P/W600EUT-001-005	下刀固定板	PLATE	1
7	BF32026P/W600EUT-001-003	垫片	SHIM	1
8	BF32026TE1631A	摆杆	SWING BAR	1
9	BF32026P/W600EUT-001-009	弹簧片	LEAF SPRING	1
10	BF32026P/W600EUT-001-010	垫块	CUSHION BLOCK	1
11	BF32026P/W600EUT-001-012	切刀台	CUTTER TABLE	1
12	BF32026P/W600EUT-001-016	垫片	SHIM	1
13	BF32026P/W600EUT-001-011	弹簧片	LEAF SPRING	1
14	BF32026P/W600EUT-001-007	弹簧片	LEAF SPRING	1
15	BF32026P/W600EUT-001-006	垫块	CUSHION BLOCK	1
16	BF32026TE014-01/P	螺钉	SCREW	1
17	BF32026TE1099/P	螺钉	SCREW	3
18	BF32026P/W600EUT-001-017	垫片	SHIM	1
19	BF32026P/W600EUT-001-026	弹簧	SPRING	1
20	BF32026TE1104/P	弹簧	SPRING	1
21	BF32026350218.5A	下切刀	LOWER CUTTER	1
22	BF32026350220.A	动刀	MOVE THE KNIFE	1
23	BF32026TE910.B	螺钉	SCREW	1
24	BF32026P/W600EUT-001-008	过线	LINE CROSSING	4

25	BF32026SM250/S	螺钉	SCREW	1
26	BF32026P/W600EUT-001-013	压板	PLATE	2
27	BF32026TE912.A	螺钉	SCREW	1
28	BF32026P/W600EUT-001-025	垫块	CUSHION BLOCK	1
29	BF32026GB/T873-1.4X6-20	铆钉	RIVET	1
30	BF32026SM230/S	螺钉	SCREW	1
31	BF32026TE1125C	垫圈	WASHER	2
32	BF32026TE1744A	垫圈	WASHER	3
33	BF32026VTE1743	螺钉	SCREW	1
34	BF32026TE1743.A	螺钉	SCREW	4
35	BF32026GB/T70.1-M6X16-12	螺钉	SCREW	2
36	BF32026P/W600EUT-001-002	垫片	SHIM	2
37	BF32026TE911.A	螺钉	SCREW	2
38	BFBPDCYZJ-JX	下(剪线)电磁铁组件 (600)	ELECTROMAGNET	1
39	BF31016P/W600EUT-001-002	连接线	POWER CORD	1
40	BF32026P/JXZZ-1	下剪刀组件	SLICE KNIFE COMPONENTS	1



二十八、抬压脚电磁铁

序号 NO.	品号 CODE	名称	NAME	数量 Number
4	TE2274	电磁铁	ELECTROMAGNET	1
5	BF31016P/W600ELFEB-003	电磁铁固定板	PLATE	1
6	BF31016GB/T70.1-M5X12-12	螺钉	SCREW	3
7	BF31016SDCT-7	连接头(塑料)	CONNECTOR	1
8	BF31016GB/T70.1-M6X16-12	螺钉	SCREW	2
9	BF31016GB/T93-6-65Mn-PH	弹垫	SHIM	2
10	BF31016GB/T97.1-6-140HV	垫片	SHIM	2
11	BF31016GB/T6177.1-M10-8	螺母	NUT	1
12	BWDCT-TY-1	上(抬压脚)电磁铁组件(500)	ELECTROMAGNET	1



二十九、附件部件

序号 NO.	品号 CODE	名称	NAME	数量 Number
1	BF700M184	固定螺钉	SCREW	4
2	BF31016206337	垫片	SHIM	16
3	BF700M183	固定头	FIXED HEAD	4
4	BF310162063381	机头减震垫	NOSE SHOCK PAD	4
5	BF700M186	连接套	CONNECTING SLEEVE	4
6	SCJ6004	内六角扳手3mm	INNER HEXAGON SPANNER	1
7	SCJ6003	内六角扳手2.5mm	INNER HEXAGON SPANNER	1
8	SCJ6002	内六角扳手2mm	INNER HEXAGON SPANNER	1
9	SCJ6005	内六角扳手4mm	INNER HEXAGON SPANNER	1
10	SCJ6007	内六角扳手6mm	INNER HEXAGON SPANNER	1
11	SCJ6006	内六角扳手5mm	INNER HEXAGON SPANNER	1
12	BFB00ZBED	螺丝刀(中)	BOLT DRIVER	1
13	BFB00DBFD	螺丝刀(大)	BOLT DRIVER	1
14	BF700M1916	镊子	TWEEZERS	1
15	BF700M156	纸滤油器	PAPER OIL FILTER	1
16	BF700M197	7mm扳手	WRENCH	1
17	BF700M198	8mm扳手	WRENCH	1
18	BF31016205467	减震垫(薄)	SHOCK PAD (THIN)	4
19	BFB00FJD	附件袋	ACCESSORY BAG	1
20	BF700M193	硅油壶	SILICONE OIL POT	1
21	BFB00DYH	大油壶	BIG OIL POT	1
22	BF700M195	小油壶	SMALL OIL POT	1
23	BF31016YD	漏斗	OIL HOPPER	1
24	BF31016259000	承重板	BEARING PLATE	2
25	BF3101611JZ	UY128GAS-11#机针	NERDLE	4
26	BF310167027	螺钉	SCREW	2
27	BF310167093	螺钉	SCREW	4
28	KR3026	脚踏拉杆	PEDAL LEVER	1
29	12040012	脚踏开关组件	FOOT SWITCH ASSEMBLY	1
30	BF31016LT	链条、链钩组件	CHAIN	1
31	BF700M199	1.5mm内六角扳手	INNER HEXAGON SPANNER	1
32	BF31016206329	锁板	LOCKING PLATE	1
33	BF32026MG	毛根	HAIKY ROOT	1
34	SCJ6036	卡扣	CLASP	3
35	14060017	ST5×20自攻螺丝	SCREW	5
37	BF700M17	线架组件	CABLE RACK ASSEMBLY	1
38	BF310164554	螺钉 (M3×3)	SCREW	6
39	BF3202625023691	导布连接板	BRACKET ASSEMBLY	1
40	BF310167028	螺钉	SCREW	2
41	BF31016204585	垫圈	WASHER	2
42	BF32026207073	螺钉	SCREW	4
43	SCJ2081	自攻螺钉	SCREW	4
44	BF32026207074	卡簧	PLAT SPRING	4
45	SCJ3023	垫圈	WASHER	4